




Installation manual

Daikin Altherma 3 R F



<https://daikintechdatahub.eu>



EBVH11S18+23DJ6V
EBVH11S18+23DJ9W
EBVH16S18+23DJ6V
EBVH16S18+23DJ9W

EBVX11S18+23DJ6V
EBVX11S18+23DJ9W
EBVX16S18+23DJ6V
EBVX16S18+23DJ9W

CE - DECLARACION-DE-CONFORMITY
CE - KONFORMITEITSVERKLARING
CE - DICHAPOZACIUNE-DE-CONFORMITA
CE - ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ
CE - DECLARACIÓN-DE-CONFORMIDAD
CE - DICHAPARAZIONE-DE-CONFORMITA
CE - ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ
CE - FORSKARAN-OM-ÖVERENSÄMMELSE

01 continuation of previous page
02 Fortsetzung der vorherigen Seite:
03 suite de la page précédente:
04 vervolg van vorige pagina:

01 Specifications of the models to which this declaration relates:
02 Konstruktionsskizzen der Modelle auf die sich diese Erklärung bezieht:
03 Specifications of conception des modèles auxquels se rapporte cette déclaration:
04 Överspecificationer van de modellen waarop deze verklaring betrekking heeft:
05 Especificaciones de diseño de los modelos a los cuales hace referencia esta declaración:
06 Specifiche di progetto dei modelli cui fa riferimento la presente dichiarazione:

01 Maximum allowable pressure (PS): <PS> (bar)
• Minimum maximum allowable temperature (TS):
• TSmin: Minimum temperature at low pressure side <L> (°C)
• TSmax: Saturated temperature corresponding with the maximum allowable pressure (PS): <PS> (°C)
• Refrigerant: <R>

• Setting of pressure safety device: <PS> (bar)
• Manufacturing number and manufacturing year: refer to model nameplate
• Minimal zulassung Druck (PS): <PS> (bar)

• TSmin: Mindesttemperatur auf der Niederdruckseite <L> (°C)
• TSmax: Sättigungstemperatur auf der dem maximal zulässigen Druck (PS) entspricht: <PS> (°C)
• Kältemittel: <R>

• Einstellung der Druck-Schutzvorrichtung: <PS> (bar)
• Herstellerungsnummer und Herstellungsjahr: siehe Typenschild des Modells

03 Pressure maxima admissible (PS): <PS> (bar)
• Temperature minimum/maximum admissible (TS):
• TSmin: Température minimum côté basse pression: <L> (°C)
• TSmax: Température saturée correspondante à la pression maximale admissible (PS): <PS> (°C)

• Réfrigérant: <R>
• Réglage du dispositif de sécurité de pression: <PS> (bar)
• Numéro de fabrication et année de fabrication: se reporter à la petite étiquette synoptique du modèle

04 Minimal maximum allowable temperature (TS):
• TSmin: Minimumtemperatur aan lage drukzijde <L> (°C)
• TSmax: Verzadigde temperatuur bij overeenkomstig met de maximal toelaten druk (PS): <PS> (°C)
• Koudemiddel: <R>

• Instelling van druedveiligheid: <PS> (bar)
• Fabricagenummer en fabricagejaar: zie naamplaat model

05 Pressure maxima admissible (PS): <PS> (bar)
• Temperature minimum/maximum admissible (TS):
• TSmin: Minimumtemperatura en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de especificaciones técnicas del modelo

CE - IZJAVA O SKLADNOSTI
CE - VASTANUSKELARUSTOON
CE - DECLARAȚIA DE CONFORMITATE
CE - ДЕКЛАРАЦИЯ О СООТВЕТСТВИИ
CE - DECLARAȚIE DE CONFORMITATE

15 continuation of previous page:
16 editie eerdere teksten:
17 editie eerdere teksten:
18 editie eerdere teksten:

13 Tafta Inicijativa koskevanj mašlin rakeminarjenosti:
14 Specificacije dizajna za modele na koje se ova izjava odnosi:
15 A plan nylakozat tárgyiak képező modellek tervezési jellemzői:
16 Specificațiile de construcție pentru modelele care sunt declarate în conformitate:
17 Specificațiile de construcție ale modelelor la care se referă această declarație:
18 Specificațiile tehnice de proiectare pentru modelele, la care se referă această declarație:
19 Specificațiile tehnice de proiectare pentru modelele, la care se referă această declarație:

15 Najveći dopušten tlak (PS): <PS> (bar)
• Najviša dopuštena temperatura (TS):
• TSmin: Minimalna temperatura na niskom pritisku: <L> (°C)
• TSmax: Standardna temperatura koja odgovara najvećem dopuštenom tlaku (PS): <PS> (°C)
• Radiator: <R>

• Postavke sigurnosne naprave za tlak: <PS> (bar)
• Proizvodni broj i godina proizvodnje: pogledajte natpisnu ploču modela

16 Legnagyobb megengedhető nyomás (PS): <PS> (bar)
• Legnagyobb megengedhető hőmérséklet (TS):
• TSmin: Legkisebb megengedhető hőmérséklet a kis nyomású oldalon: <L> (°C)
• TSmax: Legnagyobb megengedhető hőmérséklet a kis nyomású oldalon: <PS> (°C)

• Szilártsági berendezés: <PS> (bar)
• Gyártási szám és gyártási év: lásd a berendezés azatárképén

17 Maksymalny dopuszczalny ciśnienie (PS): <PS> (bar)
• Minimalna temperatura na niskim ciśnieniu: <L> (°C)
• Minimalna temperatura na stonę wysokiego ciśnienia: <PS> (°C)
• Temperatura nasytienia odpowiadająca maksymalnemu dopuszczalnemu ciśnieniu (PS): <PS> (°C)

• Ciepłota chłodzenia: <R>
• Nastawa ciśnieniowego urządzenia zabezpieczającego: <PS> (bar)
• Numer fabryczny oraz rok produkcji: patrz tabliczkę znamionową modelu

18 Presiune maximă admisibilă (PS): <PS> (bar)
• Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă pe partea de presiune joasă: <L> (°C)
• TSmax: Temperatura saturată corespunzătoare presiunii maxime admisibile (PS): <PS> (°C)

• Agent frigorific: <R>
• Reglarea dispozitivului de siguranță pentru presiune: <PS> (bar)
• Numărul de fabricație și anul de fabricație: consultați placa de identificare a modelului

19 Temperatura mínima admisible (TS):
• TSmin: Temperatura mínima en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

20 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă pe partea de presiune joasă: <L> (°C)
• TSmax: Temperatura saturată corespunzătoare presiunii maxime admisibile (PS): <PS> (°C)

• Agent frigorific: <R>
• Reglarea dispozitivului de siguranță pentru presiune: <PS> (bar)
• Numărul de fabricație și anul de fabricație: consultați placa de identificare a modelului

CE - IZJAVA O SKLADNOSTI
CE - VASTANUSKELARUSTOON
CE - DECLARAȚIA DE CONFORMITATE
CE - ДЕКЛАРАЦИЯ О СООТВЕТСТВИИ
CE - DECLARAȚIE DE CONFORMITATE

19 continuation of previous page:
20 editie eerdere teksten:
21 editie eerdere teksten:
22 editie eerdere teksten:

20 Deklaratsiooni alla kuuluvate mudelite disainispetsifikatsioonid:
21 Doenarshi opredeleniye modely, k korym se otnosya deklariatsiya:
22 Konstruktsionnye spetsifikatsii modely, kurye slyuzh sa dlya deklaratsii:
23 To modelu dizaina spetsifikatsii, iz kurykh atlyasay sh deklaratsii:
24 Konstruktivnye spetsifikatsii modely, korykh sh lyuzh oty vyshleniye:
25 Bu bilidninn ligiti otdygu modellerin Tasarm Ozallitleri:

21 Maksimálny dovoljen tlak (PS): <PS> (bar)
• Minimalna temperatura na niskom pritisku: <L> (°C)
• TSmin: Minimalna temperatura na niskom pritisku: <L> (°C)
• TSmax: Standardna temperatura koja odgovara najvećem dopuštenom tlaku (PS): <PS> (°C)
• Radiator: <R>

• Postavke sigurnosne naprave za tlak: <PS> (bar)
• Proizvodni broj i godina proizvodnje: pogledajte natpisnu ploču modela

22 Legnagyobb megengedhető nyomás (PS): <PS> (bar)
• Legnagyobb megengedhető hőmérséklet (TS):
• TSmin: Legkisebb megengedhető hőmérséklet a kis nyomású oldalon: <L> (°C)
• TSmax: Legnagyobb megengedhető hőmérséklet a kis nyomású oldalon: <PS> (°C)

• Szilártsági berendezés: <PS> (bar)
• Gyártási szám és gyártási év: lásd a berendezés azatárképén

23 Maksymalny dopuszczalny ciśnienie (PS): <PS> (bar)
• Minimalna temperatura na niskim ciśnieniu: <L> (°C)
• Minimalna temperatura na stonę wysokiego ciśnienia: <PS> (°C)
• Temperatura nasytienia odpowiadająca maksymalnemu dopuszczalnemu ciśnieniu (PS): <PS> (°C)

• Ciepłota chłodzenia: <R>
• Nastawa ciśnieniowego urządzenia zabezpieczającego: <PS> (bar)
• Numer fabryczny oraz rok produkcji: patrz tabliczkę znamionową modelu

24 Presiune maximă admisibilă (PS): <PS> (bar)
• Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă pe partea de presiune joasă: <L> (°C)
• TSmax: Temperatura saturată corespunzătoare presiunii maxime admisibile (PS): <PS> (°C)

• Agent frigorific: <R>
• Reglarea dispozitivului de siguranță pentru presiune: <PS> (bar)
• Numărul de fabricație și anul de fabricație: consultați placa de identificare a modelului

25 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

26 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă pe partea de presiune joasă: <L> (°C)
• TSmax: Temperatura saturată corespunzătoare presiunii maxime admisibile (PS): <PS> (°C)

• Agent frigorific: <R>
• Reglarea dispozitivului de siguranță pentru presiune: <PS> (bar)
• Numărul de fabricație și anul de fabricație: consultați placa de identificare a modelului

CE - ATTIKTES-DEKLARACIJA
CE - ATTIKTES-DEKLARACIJA
CE - ATTIKTES-DEKLARACIJA
CE - ATTIKTES-DEKLARACIJA
CE - ATTIKTES-DEKLARACIJA

22 continuation of previous page:
23 editie eerdere teksten:
24 editie eerdere teksten:
25 editie eerdere teksten:

22 Deklaratsiooni alla kuuluvate mudelite disainispetsifikatsioonid:
23 Doenarshi opredeleniye modely, k korym se otnosya deklariatsiya:
24 Konstruktsionnye spetsifikatsii modely, kurye slyuzh sa dlya deklaratsii:
25 To modelu dizaina spetsifikatsii, iz kurykh atlyasay sh deklaratsii:
26 Konstruktivnye spetsifikatsii modely, korykh sh lyuzh oty vyshleniye:
27 Bu bilidninn ligiti otdygu modellerin Tasarm Ozallitleri:

24 Maksimálny dovoljen tlak (PS): <PS> (bar)
• Minimalna temperatura na niskom pritisku: <L> (°C)
• TSmin: Minimalna temperatura na niskom pritisku: <L> (°C)
• TSmax: Standardna temperatura koja odgovara najvećem dopuštenom tlaku (PS): <PS> (°C)
• Radiator: <R>

• Postavke sigurnosne naprave za tlak: <PS> (bar)
• Proizvodni broj i godina proizvodnje: pogledajte natpisnu ploču modela

25 Legnagyobb megengedhető nyomás (PS): <PS> (bar)
• Legnagyobb megengedhető hőmérséklet (TS):
• TSmin: Legkisebb megengedhető hőmérséklet a kis nyomású oldalon: <L> (°C)
• TSmax: Legnagyobb megengedhető hőmérséklet a kis nyomású oldalon: <PS> (°C)

• Szilártsági berendezés: <PS> (bar)
• Gyártási szám és gyártási év: lásd a berendezés azatárképén

26 Maksymalny dopuszczalny ciśnienie (PS): <PS> (bar)
• Minimalna temperatura na niskim ciśnieniu: <L> (°C)
• Minimalna temperatura na stonę wysokiego ciśnienia: <PS> (°C)
• Temperatura nasytienia odpowiadająca maksymalnemu dopuszczalnemu ciśnieniu (PS): <PS> (°C)

• Ciepłota chłodzenia: <R>
• Nastawa ciśnieniowego urządzenia zabezpieczającego: <PS> (bar)
• Numer fabryczny oraz rok produkcji: patrz tabliczkę znamionową modelu

27 Presiune maximă admisibilă (PS): <PS> (bar)
• Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă pe partea de presiune joasă: <L> (°C)
• TSmax: Temperatura saturată corespunzătoare presiunii maxime admisibile (PS): <PS> (°C)

• Agent frigorific: <R>
• Reglarea dispozitivului de siguranță pentru presiune: <PS> (bar)
• Numărul de fabricație și anul de fabricație: consultați placa de identificare a modelului

28 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

29 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă pe partea de presiune joasă: <L> (°C)
• TSmax: Temperatura saturată corespunzătoare presiunii maxime admisibile (PS): <PS> (°C)

• Agent frigorific: <R>
• Reglarea dispozitivului de siguranță pentru presiune: <PS> (bar)
• Numărul de fabricație și anul de fabricație: consultați placa de identificare a modelului

21 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

22 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

23 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

24 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

25 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

26 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

27 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

28 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

29 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

30 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

31 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

32 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

33 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

34 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

35 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

36 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

37 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

38 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

39 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

40 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

41 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

42 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

43 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

44 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

45 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

46 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

47 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

48 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

49 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

50 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

51 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

52 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

53 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C)

• Refrigerante: <R>
• Ajuste del presostato de seguridad: <PS> (bar)
• Número de fabricación y año de fabricación: consulte la placa de identificación del modelo

54 Temperatura minimă admisibilă (TS):
• TSmin: Temperatura minimă en el lado de baja presión: <L> (°C)
• TSmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <PS> (°C

Table of contents

1	About this document	4
2	Specific installer safety instructions	5
3	About the box	6
3.1	Indoor unit	6
3.1.1	To remove the accessories from the indoor unit	6
3.1.2	To handle the indoor unit	6
4	Unit installation	6
4.1	Preparing the installation site	6
4.1.1	Installation site requirements of the indoor unit	7
4.1.2	Special requirements for R32 units	7
4.1.3	Installation patterns	8
4.2	Opening and closing the unit	13
4.2.1	To open the indoor unit	13
4.2.2	To lower the switch box on the indoor unit	14
4.2.3	To close the indoor unit	14
4.3	Mounting the indoor unit	14
4.3.1	To install the indoor unit	14
4.3.2	To connect the drain hose to the drain	15
5	Piping installation	15
5.1	Preparing refrigerant piping	15
5.1.1	Refrigerant piping requirements	15
5.1.2	Refrigerant piping insulation	15
5.2	Connecting refrigerant piping	16
5.2.1	To connect the refrigerant piping to the indoor unit	16
5.3	Preparing water piping	16
5.3.1	To check the water volume and flow rate	16
5.4	Connecting water piping	17
5.4.1	To connect the water piping	17
5.4.2	To connect the recirculation piping	17
5.4.3	To fill the water circuit	17
5.4.4	To fill the domestic hot water tank	17
5.4.5	To insulate the water piping	17
6	Electrical installation	17
6.1	About electrical compliance	18
6.2	Guidelines when connecting the electrical wiring	18
6.3	Connections to the indoor unit	18
6.3.1	To connect the main power supply	19
6.3.2	To connect the backup heater power supply	20
6.3.3	To connect the shut-off valve	21
6.3.4	To connect the electricity meters	22
6.3.5	To connect the domestic hot water pump	22
6.3.6	To connect the alarm output	23
6.3.7	To connect the space cooling/heating ON/OFF output	23
6.3.8	To connect the changeover to external heat source	24
6.3.9	To connect the power consumption digital inputs	24
6.3.10	To connect the safety thermostat (normally closed contact)	25
6.3.11	To connect a Smart Grid	25
6.4	After connecting the electrical wiring to the indoor unit	27
7	Configuration	27
7.1	Overview: Configuration	27
7.1.1	To access the most used commands	28
7.2	Configuration wizard	29
7.2.1	Configuration wizard: Language	29
7.2.2	Configuration wizard: Time and date	29
7.2.3	Configuration wizard: System	29
7.2.4	Configuration wizard: Backup heater	30
7.2.5	Configuration wizard: Main zone	31
7.2.6	Configuration wizard: Additional zone	31
7.2.7	Configuration wizard: Tank	32

7.3	Weather-dependent curve	32
7.3.1	What is a weather-dependent curve?	32
7.3.2	2-points curve	33
7.3.3	Slope-offset curve	33
7.3.4	Using weather-dependent curves	34
7.4	Settings menu	34
7.4.1	Main zone	34
7.4.2	Additional zone	34
7.4.3	Information	35
7.5	Menu structure: Overview installer settings	36
8	Commissioning	37
8.1	Checklist before commissioning	37
8.2	Checklist during commissioning	37
8.2.1	To check the minimum flow rate	38
8.2.2	To perform an air purge	38
8.2.3	To perform an operation test run	38
8.2.4	To perform an actuator test run	38
8.2.5	To perform an underfloor heating screed dryout	39
9	Hand-over to the user	39
10	Technical data	40
10.1	Piping diagram: Indoor unit	40
10.2	Wiring diagram: Indoor unit	41

1 About this document

Target audience

Authorised installers

Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
 - Safety instructions that you must read before installing
 - Format: Paper (in the box of the indoor unit)
- **Operation manual:**
 - Quick guide for basic usage
 - Format: Paper (in the box of the indoor unit)
- **User reference guide:**
 - Detailed step-by-step instructions and background information for basic and advanced usage
 - Format: Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>
- **Installation manual – Outdoor unit:**
 - Installation instructions
 - Format: Paper (in the box of the outdoor unit)
- **Installation manual – Indoor unit:**
 - Installation instructions
 - Format: Paper (in the box of the indoor unit)
- **Installer reference guide:**
 - Preparation of the installation, good practices, reference data, ...
 - Format: Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>
- **Addendum book for optional equipment:**
 - Additional info about how to install optional equipment
 - Format: Paper (in the box of the indoor unit) + Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>

2 Specific installer safety instructions

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

The original documentation is written in English. All other languages are translations.

Technical engineering data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin Business Portal (authentication required).

Online tools

In addition to the documentation set, some online tools are available for installers:

• Daikin Technical Data Hub

- Central hub for technical specifications of the unit, useful tools, digital resources, and more.
- Publicly accessible via <https://daikintechdatahub.eu>.

• Heating Solutions Navigator

- Digital toolbox that offers a variety of tools to facilitate the installation and configuration of heating systems.
- To access Heating Solutions Navigator, registration to the Stand By Me platform is required. For more information, see <https://professional.standbyme.daikin.eu>.

• Daikin e-Care

- Mobile app for installers and service technicians that allows you to register, configure and troubleshoot heating systems.
- The mobile app can be downloaded for iOS and Android devices using the QR codes below. Registration to the Stand By Me platform is required to access the app.

App Store



Google Play



2 Specific installer safety instructions

Always observe the following safety instructions and regulations.

Installation site (see "[4.1 Preparing the installation site](#)" ▶ 6))



WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).



WARNING

DO NOT reuse refrigerant piping that has been used with any other refrigerant. Replace the refrigerant pipes or clean thoroughly.



WARNING

Follow the service space dimensions in this manual for correct installation of the unit. See "[4.1.1 Installation site requirements of the indoor unit](#)" ▶ 7).

Special requirements for R32 (see "[4.1.2 Special requirements for R32 units](#)" ▶ 7))



WARNING

- Do NOT pierce or burn.
- Do NOT use means to accelerate the defrosting process or to clean the equipment, other than those recommended by the manufacturer.
- Be aware that R32 refrigerant does NOT contain an odour.



WARNING

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).



WARNING

Make sure installation, servicing, maintenance and repair comply with instructions from Daikin and with applicable legislation and are executed ONLY by authorised persons.

Opening and closing the unit (see "[4.2 Opening and closing the unit](#)" ▶ 13))



DANGER: RISK OF ELECTROCUTION



DANGER: RISK OF BURNING/SCALDING

Mounting the indoor unit (see "[4.3 Mounting the indoor unit](#)" ▶ 14))



WARNING

Fixing method of the indoor unit MUST be in accordance with the instructions from this manual. See "[4.3 Mounting the indoor unit](#)" ▶ 14).

Piping installation (see "[5 Piping installation](#)" ▶ 15))



WARNING

Field piping method MUST be in accordance with the instructions from this manual. See "[5 Piping installation](#)" ▶ 15).

Electrical installation (see "[6 Electrical installation](#)" ▶ 17))



DANGER: RISK OF ELECTROCUTION



WARNING

Electrical wiring connection method MUST be in accordance with the instructions from:

- This manual. See "[6 Electrical installation](#)" ▶ 17).
- The wiring diagram, which is delivered with the unit, located on the inside of the indoor unit switch box cover. For a translation of its legend, see "[10.2 Wiring diagram: Indoor unit](#)" ▶ 41).



WARNING

- All wiring MUST be performed by an authorised electrician and MUST comply with the applicable legislation.
- Make electrical connections to the fixed wiring.
- All components procured on-site and all electrical construction MUST comply with the applicable legislation.

3 About the box



WARNING

If the supply cord is damaged, it **MUST** be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



WARNING

ALWAYS use multicore cable for power supply cables.




CAUTION

Do **NOT** push or place redundant cable length in the unit.



WARNING

Make sure that the electrical wiring does **NOT** touch the refrigerant gas pipe, which can be very hot.



a Refrigerant gas pipe



WARNING

The backup heater **MUST** have a dedicated power supply and **MUST** be protected by the safety devices required by the applicable legislation.



CAUTION

To guarantee the unit is completely earthed, **ALWAYS** connect the backup heater power supply and the earth cable.



INFORMATION

Details of type and rating of fuses, or rating of circuit breakers are described in "6 Electrical installation" [p 17].

Commissioning (see "8 Commissioning" [p 37])





WARNING

Commissioning method **MUST** be in accordance with the instructions from this manual. See "8 Commissioning" [p 37].




WARNING

Air purging heat emitters or collectors. Before you purge air from heat emitters or collectors, check if  or  is displayed on the home screen of the user interface.

- If not, you can purge air immediately.
- If yes, make sure that the room where you want to purge air is sufficiently ventilated. **Reason:** Refrigerant might leak into the water circuit, and subsequently into the room when you purge air from the heat emitters or collectors.

- Bring the packed unit as close as possible to its final installation position to prevent damage during transport.
- Unpack the indoor unit completely according to the instructions mentioned on the unpacking instructions sheet.


3.1.1 To remove the accessories from the indoor unit



- a Shut-off valves for water circuit
- b Overpressure bypass valve
- c General safety precautions
- d Addendum book for optional equipment
- e Indoor unit installation manual
- f Operation manual
- g Sealing rings for shut-off valves (space heating water circuit)
- h Sealing rings for field-supplied shut-off valves (domestic hot water circuit)
- i Sealing tape for low voltage wiring intake

3.1.2 To handle the indoor unit

Use the handles at the back and at the bottom to carry the unit.



- a Handles at the back of the unit
- b Handles at the bottom of the unit. Carefully tilt the unit to the back so that the handles become visible.

4 Unit installation

4.1 Preparing the installation site



WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).

3 About the box

3.1 Indoor unit

- At delivery, the unit **MUST** be checked for damage. Any damage **MUST** be reported immediately to the claims agent of the carrier.



WARNING

DO NOT reuse refrigerant piping that has been used with any other refrigerant. Replace the refrigerant pipes or clean thoroughly.

4.1.1 Installation site requirements of the indoor unit

- The indoor unit is designed for indoor installation only and for the following ambient temperatures:
 - Space heating operation: 5~30°C
 - Space cooling operation: 5~35°C
 - Domestic hot water production: 5~35°C



INFORMATION

Cooling is only applicable in case of:


- Reversible models
- Heating only models + conversion kit (EKHVCONV*)

- Mind the following measurements guidelines:

Maximum refrigerant piping length ^(a) between indoor unit and outdoor unit	50 m
Minimum refrigerant piping length ^(a) between indoor unit and outdoor unit	3 m
Maximum height difference between indoor unit and outdoor unit	30 m

^(a) Refrigerant piping length is the one-way length of liquid piping.

- Mind the following spacing installation guidelines:



(mm)



INFORMATION

If you have limited installation space, do the following before installing the unit in its final position: ["4.3.2 To connect the drain hose to the drain"](#) [p. 15]. It requires to remove one or both side panels.

4.1.2 Special requirements for R32 units

Because the total refrigerant charge in the system is ≥ 1.84 kg, the room where you install the indoor unit must comply with the conditions described in ["4.1.3 Installation patterns"](#) [p. 8].



WARNING

- Do NOT pierce or burn.
- Do NOT use means to accelerate the defrosting process or to clean the equipment, other than those recommended by the manufacturer.
- Be aware that R32 refrigerant does NOT contain an odour.



WARNING

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater) and have a room size as specified below.



NOTICE

- Do NOT re-use joints and copper gaskets which have been used already.
- Joints made in installation between parts of refrigerant system shall be accessible for maintenance purposes.



WARNING

Make sure installation, servicing, maintenance and repair comply with instructions from Daikin and with applicable legislation and are executed ONLY by authorised persons.



NOTICE






- Pipework shall be protected from physical damage.
- Installation of pipework shall be kept to a minimum.

4 Unit installation

4.1.3 Installation patterns

Depending on the type of room in which you install the indoor unit, different installation patterns are allowed:

Room type	Allowed patterns
Living room, kitchen, garage, attic, basement, storage room	1, 2, 3
Technical room (i.e. room that is NEVER occupied by persons)	1, 2, 3, 4


	PATTERN 1	PATTERN 2	PATTERN 3	PATTERN 4
				
Ventilation openings	N/A	Between room A and B	N/A	Between room A and outside
Minimum floor area	Room A	Room A + Room B	N/A	N/A
Chimney	Might be needed	Might be needed	Connected to outside	N/A
Release in case of refrigerant leakage	Inside room A	Inside room A	Outside	Inside room A
Restrictions	See "PATTERN 1" ▶ 9], "PATTERN 2" ▶ 9], "PATTERN 3" ▶ 11], and "Tables for PATTERN 1, 2 and 3" ▶ 11]			See "PATTERN 4" ▶ 13]

A	Room A (= room where indoor unit is installed)
B	Room B (= adjacent room)
a	If no chimney is installed, this is the default point of release in case of refrigerant leakage. If needed, you can connect a chimney here: <ul style="list-style-type: none"> Unit's connection point for the chimney = 1" male thread. Use a compatible counterpart for the chimney. Make sure the connection is airtight.
b	Chimney
c1	Bottom opening for natural ventilation
c2	Top opening for natural ventilation
H_{release}	Actual release height: 1a/2a : Without chimney. From floor to top of the unit. <ul style="list-style-type: none"> For 180 l units => H_{release} = 1.66 m For 230 l units => H_{release} = 1.86 m 1b/2b : With chimney. From floor to top of the chimney. <ul style="list-style-type: none"> For 180 l units => H_{release} = 1.66 m + Chimney height For 230 l units => H_{release} = 1.86 m + Chimney height
3a	Installation with chimney connected to the outside. The release height is not relevant. There are no requirements to the minimum floor area.
N/A	Not applicable

Minimum floor area / Release height:

- The minimum floor area requirements depend on the release height of the refrigerant in case of a leakage. The higher the release height, the lower the minimum floor area requirements.
- The default point of release (without chimney) is at the top of the unit. To decrease the minimum floor area requirements, you can increase the release height by installing a chimney. If the chimney leads outside of the building, there are no requirements anymore to the minimum floor area.
- You can also take advantage of the floor area of the adjacent room (= room B) by providing ventilation openings between the two rooms.
- For installations in technical rooms (i.e. room that is NEVER occupied by persons), additionally to patterns 1, 2 and 3, you can also use **PATTERN 4**. For this pattern there are no requirements to the minimum floor area if you provide 2 openings (one at the bottom, one at the top) between the room and the outside to ensure natural ventilation. The room must be protected from frost.

PATTERN 1




PATTERN 2


PATTERN 2: Conditions ventilation openings

If you want to take advantage of the floor area of the adjacent room, you must provide 2 openings (one at the bottom, one at the top) between the rooms to ensure natural ventilation. The openings must comply with the following conditions:


- **Bottom opening (A_{nv}):**
 - Must be a permanent opening that cannot be closed.
 - Must be completely located between 0 and 300 mm from the floor.
 - Must be $\geq A_{nv-min}$ (minimum bottom opening area).
 - $\geq 50\%$ of the required opening area A_{nv-min} must be ≤ 200 mm from the floor.
 - The bottom of the opening must be ≤ 100 mm from the floor.
 - If the opening starts from the floor, the height of the opening must be ≥ 20 mm.
- **Top opening:**
 - Must be a permanent opening that cannot be closed.
 - Must be $\geq 50\%$ of A_{nv-min} (minimum bottom opening area).
 - Must be ≥ 1.5 m from the floor.



4 Unit installation



PATTERN 3



Tables for PATTERN 1, 2 and 3

Table 1: Minimum floor area

For intermediate refrigerant charges, use the row with the higher value. **Example:** If the refrigerant charge is 4.3 kg, use the row of 4.5 kg.

Charge (kg)	Minimum floor area (m ²)	
	Release height without chimney (m)	
	1.66 (Unit=180 l)	1.86 (Unit=230 l)
3.8	16.04	12.76
4	17.77	14.14
4.5	22.49	17.90
5	27.76	22.09
5.5	33.59	26.73
5.8	37.36	29.73

Table 2: Minimum release height

Take the following into account:

- For intermediate floor areas, use the column with the lower value. **Example:** If the floor area is 22.50 m², use the column of 20.00 m².
- For intermediate refrigerant charges, use the row with the higher value. **Example:** If the refrigerant charge is 4.3 kg, use the row of 4.5 kg.
- (*): The release height of the unit without chimney (for 180 l units: 1.66 m; for 230 l units: 1.86 m) is already higher than the minimum required release height. => OK (no chimney needed).

Charge (kg)	Minimum release height (m)						
	Floor area (m ²)						
	5.00	10.00	15.00	20.00	25.00	30.00	35.00
3.8	3.30	2.10	1.72	(*)	(*)	(*)	(*)
4	3.47	2.21	1.81	(*)	(*)	(*)	(*)
4.5	3.91	2.49	2.03	1.76	(*)	(*)	(*)
5	4.34	2.77	2.26	1.96	1.75	(*)	(*)
5.5	4.78	3.04	2.49	2.15	1.93	1.76	(*)
5.8	5.04	3.21	2.62	2.27	2.03	1.85	1.72

4 Unit installation

Table 3: Maximum chimney length

When installing a chimney, the chimney length must be less than the maximum chimney length.

- Use the columns with the correct refrigerant charge. For intermediate refrigerant charges, use the columns with the higher value. **Example:** If the refrigerant charge is 4.0 kg, use the columns of 5.8 kg.
- For intermediate diameters, use the column with the lower value. **Example:** If the diameter is 23 mm, use the column of 22 mm.
- X: Not allowed

Maximum chimney length (m) – In case of Refrigerant charge=3.8 kg (and T=60°C)						In case of Refrigerant charge=5.8 kg (and T=60°C)				
Chimney	Inside diameter of chimney (mm)					Inside diameter of chimney (mm)				
	20	22	24	26	28	20	22	24	26	28
Straight pipe	19.03	33.90	55.16	84.54	124.06	3.37	9.47	18.40	30.91	47.91
1× 90° elbow	17.23	31.92	53.00	82.20	121.54	1.57	7.49	16.24	28.57	45.39
2× 90° elbow	15.43	29.94	50.84	79.86	119.02	X	5.51	14.08	26.23	42.87
3× 90° elbow	13.63	27.96	48.68	77.52	116.50	X	3.53	11.92	23.89	40.35

Table 4: Minimum bottom opening area for natural ventilation

Take the following into account:

- Use the correct table. For intermediate refrigerant charges, use the table with the higher value. **Example:** If the refrigerant charge is 4.3 kg, use the table of 4.8 kg.
- For intermediate floor areas, use the column with the lower value. **Example:** If the floor area is 12.50 m², use the column of 10.00 m².
- For intermediate release height values, use the row with the lower value. **Example:** If the release height is 1.90 m, use the row of 1.86 m.
- A_{nv}: Bottom opening area for natural ventilation.
- A_{nv-min}: Minimum bottom opening area for natural ventilation.
- (*): Already OK (no ventilation openings needed).


A _{nv-min} (dm ²) – In case of Refrigerant charge=3.8 kg							
Release height (m)	Floor area of room A (m ²) [! NOT room A + room B !]						
	5.00	10.00	15.00	20.00	25.00	30.00	35.00
1.66	4.6	2.2	0.4	(*)	(*)	(*)	(*)
1.86	3.8	1.1	(*)	(*)	(*)	(*)	(*)
2.06	3.1	0.2	(*)	(*)	(*)	(*)	(*)
2.26	2.5	(*)	(*)	(*)	(*)	(*)	(*)
2.46	1.9	(*)	(*)	(*)	(*)	(*)	(*)
2.66	1.4	(*)	(*)	(*)	(*)	(*)	(*)
2.86	0.9	(*)	(*)	(*)	(*)	(*)	(*)
3.06	0.5	(*)	(*)	(*)	(*)	(*)	(*)

A _{nv-min} (dm ²) – In case of Refrigerant charge=4.8 kg							
Release height (m)	Floor area of room A (m ²) [! NOT room A + room B !]						
	5.00	10.00	15.00	20.00	25.00	30.00	35.00
1.66	7.0	4.9	3.4	1.8	0.2	(*)	(*)
1.86	6.1	3.7	2.0	0.1	(*)	(*)	(*)
2.06	5.3	2.7	0.7	(*)	(*)	(*)	(*)
2.26	4.6	1.7	(*)	(*)	(*)	(*)	(*)
2.46	3.9	0.8	(*)	(*)	(*)	(*)	(*)
2.66	3.3	(*)	(*)	(*)	(*)	(*)	(*)
2.86	2.8	(*)	(*)	(*)	(*)	(*)	(*)
3.06	2.3	(*)	(*)	(*)	(*)	(*)	(*)

A _{nv-min} (dm ²) – In case of Refrigerant charge=5.8 kg							
Release height (m)	Floor area of room A (m ²) [! NOT room A + room B !]						
	5.00	10.00	15.00	20.00	25.00	30.00	35.00
1.66	9.5	7.7	6.5	5.1	3.7	2.2	0.7
1.86	8.4	6.3	4.8	3.2	1.6	(*)	(*)
2.06	7.5	5.1	3.4	1.6	(*)	(*)	(*)
2.26	6.7	4.0	2.1	0.1	(*)	(*)	(*)
2.46	5.9	3.1	0.9	(*)	(*)	(*)	(*)
2.66	5.3	2.2	(*)	(*)	(*)	(*)	(*)
2.86	4.6	1.3	(*)	(*)	(*)	(*)	(*)
3.06	4.1	0.5	(*)	(*)	(*)	(*)	(*)

PATTERN 4

PATTERN 4 is only allowed for installations in technical rooms (i.e. room that is NEVER occupied by persons). For this pattern there are no requirements to the minimum floor area if you provide 2 openings (one at the bottom, one at the top) between the room and the outside to ensure natural ventilation. The room must be protected from frost.



A	Unoccupied room where the indoor unit is installed. Must be protected from frost.
a1	A_{nv}: Bottom opening for natural ventilation between the unoccupied room and the outside. <ul style="list-style-type: none"> Must be a permanent opening that cannot be closed. Must be above ground level. Must be completely located between 0 and 300 mm from the floor of the unoccupied room. Must be $\geq A_{nv-min}$ (minimum bottom opening area as specified in the table below). $\geq 50\%$ of the required opening area A_{nv-min} must be ≤ 200 mm from the floor of the unoccupied room. The bottom of the opening must be ≤ 100 mm from the floor of the unoccupied room. If the opening starts from the floor, the height of the opening must be ≥ 20 mm.
a2	Top opening for natural ventilation between room A and the outside. <ul style="list-style-type: none"> Must be a permanent opening that cannot be closed. Must be $\geq 50\%$ of A_{nv-min} (minimum bottom opening area as specified in the table below). Must be ≥ 1.5 m from the floor of the unoccupied room.

A_{nv-min} (minimum bottom opening area for natural ventilation)

The minimum bottom opening area for natural ventilation between the unoccupied room and the outside depends on the total refrigerant in the system. For intermediate refrigerant charges, use the row with the higher value. **Example:** If the refrigerant charge is 4.3 kg, use the row of 4.4 kg.


Total refrigerant charge (kg)	A _{nv-min} (dm ²)
3.8	9.9
4	10.1
4.2	10.4
4.4	10.6
4.6	10.9
4.8	11.1
5	11.3
5.2	11.5
5.4	11.8

Total refrigerant charge (kg)	A _{nv-min} (dm ²)
5.6	12.0
5.8	12.2

4.2 Opening and closing the unit

4.2.1 To open the indoor unit


Overview



- a Top panel
- b User interface panel
- c Switch box cover
- d Front panel
- e High voltage switch box cover

Open

- 1 Remove the top panel.




- 2 Remove the user interface panel. Open the hinges at the top and slide the top panel upwards.




NOTICE

If you remove the user interface panel, also disconnect the cables from the back of the user interface panel to prevent damage.




- 3 Remove the switch box cover.

4 Unit installation




4 If necessary, remove the front plate. This is, for example, necessary in the following cases:

- "4.2.2 To lower the switch box on the indoor unit" ► 14]
- "4.3.2 To connect the drain hose to the drain" ► 15]
- When you need access to the high voltage switch box



5 If you need access to the high voltage components, remove the high voltage switch box cover.




4.2.2 To lower the switch box on the indoor unit


During the installation, you will need access to the inside of the indoor unit. To have easier front access, put the switch box lower on the unit as follows:

Prerequisite: The user interface panel and front panel have been removed.

- 1 Remove the fixing plate at the top of the unit.
- 2 Tilt the switch box to the front and lift it out of its hinges.



- 3 Place the switch box lower on the unit. Use the 2 hinges located lower on the unit.



4.2.3 To close the indoor unit

- 1 Close the cover of the switch box.
- 2 Put the switch box back into place.
- 3 Reinstall the top panel.
- 4 Reinstall the side panels.
- 5 Reinstall the front panel.
- 6 Reconnect the cables to the user interface panel.
- 7 Reinstall the user interface panel.




NOTICE

When closing the indoor unit cover, make sure that the tightening torque does NOT exceed 4.1 N•m.

4.3 Mounting the indoor unit


4.3.1 To install the indoor unit

- 1 Lift the indoor unit from the pallet and place it on the floor. Also see "3.1.2 To handle the indoor unit" ► 6].
- 2 Connect the drain hose to the drain. See "4.3.2 To connect the drain hose to the drain" ► 15].
- 3 Slide the indoor unit into position.
- 4 Adjust the height of the leveling feet to compensate for floor irregularities. The maximum allowed deviation is 1°.



NOTICE

Do NOT tilt the unit forwards:



4.3.2 To connect the drain hose to the drain


Water coming from the pressure relief valve is collected in the drain pan. The drain pan is connected to a drain hose inside the unit. You must connect the drain hose to an appropriate drain according to the applicable legislation. You can route the drain hose through the left or right side panel.

Prerequisite: The user interface panel and front panel have been removed.


- 1 Remove one of the side panels.
- 2 Cut out the rubber grommet.
- 3 Pull the drain hose through the hole.
- 4 Reattach the side panel. Ensure the water can flow through the drain tube.

It is recommended to use a tundish to collect the water.

Option 1: Through the left side panel



Option 2: Through the right side panel



5 Piping installation

5.1 Preparing refrigerant piping

5.1.1 Refrigerant piping requirements

Also see "4.1.2 Special requirements for R32 units" [p. 7] for additional requirements.

- **Piping length:** See "4.1.1 Installation site requirements of the indoor unit" [p. 7].
- **Piping material:** Phosphoric acid deoxidised seamless copper.
- **Piping connections:** Only flare and brazed connections are allowed. The indoor and outdoor units have flare connections. Connect both ends without brazing. If brazing should be needed, take the guidelines in the installer reference guide into account.
- **Flare connections:** Only use annealed material.
- **Piping diameter:**

Liquid piping	Ø9.5 mm (3/8")
Gas piping	Ø15.9 mm (5/8")

- **Piping temper grade and thickness:**

Outer diameter (Ø)	Temper grade	Thickness (t) ^(a)	
9.5 mm (3/8")	Annealed (O)	≥0.8 mm	
15.9 mm (5/8")	Annealed (O)	≥1.0 mm	

^(a) Depending on the applicable legislation and the maximum working pressure of the unit (see "PS High" on the unit name plate), larger piping thickness might be required.

5.1.2 Refrigerant piping insulation

- Use polyethylene foam as insulation material:
 - with a heat transfer rate between 0.041 and 0.052 W/mK (0.035 and 0.045 kcal/mh°C)
 - with a heat resistance of at least 120°C
- Insulation thickness

Pipe outer diameter (Ø _p)	Insulation inner diameter (Ø _i)	Insulation thickness (t)
9.5 mm (3/8")	12~15 mm	≥13 mm
15.9 mm (5/8")	17~20 mm	≥13 mm

5 Piping installation




If the temperature is higher than 30°C and the humidity is higher than RH 80%, the thickness of the insulation materials should be at least 20 mm to prevent condensation on the surface of the insulation.

5.2 Connecting refrigerant piping

See the installation manual of the outdoor unit for all guidelines, specifications and installation instructions.

5.2.1 To connect the refrigerant piping to the indoor unit

- 1 Connect the liquid stop valve from the outdoor unit to the refrigerant liquid connection of the indoor unit.



- a Refrigerant liquid connection
b Refrigerant gas connection

- 2 Connect the gas stop valve from the outdoor unit to the refrigerant gas connection of the indoor unit.

5.3 Preparing water piping



NOTICE

In case of plastic pipes, make sure they are fully oxygen diffusion tight according to DIN 4726. The diffusion of oxygen into the piping can lead to excessive corrosion.



NOTICE


Water circuit requirements. Make sure to comply with the water pressure and water temperature requirements below. For additional water circuit requirements, see the installer reference guide.

- **Water pressure – Domestic hot water.** The maximum water pressure is 4 bar. Provide adequate safeguards in the water circuit to ensure that the maximum pressure is NOT exceeded. The minimum water pressure to operate is 1 bar.
- **Water pressure – Space heating/cooling circuit.** The maximum water pressure is 3 bar. Provide adequate safeguards in the water circuit to ensure that the maximum pressure is NOT exceeded. The minimum water pressure to operate is 1 bar.
- **Water temperature.** All installed piping and piping accessories (valve, connections,...) MUST withstand the following temperatures:



INFORMATION

The following illustration is an example and might NOT match your system layout.



5.3.1 To check the water volume and flow rate

Minimum water volume

Check that the total water volume in the installation is higher than the minimum water volume, the internal water volume of the indoor unit NOT included:

If...	Then the minimum water volume is...
Cooling operation	20 l
Heating operation	20 l



NOTICE

When circulation in each space heating/cooling loop is controlled by remotely controlled valves, it is important that the minimum water volume is guaranteed, even if all of the valves are closed.

Minimum flow rate

Check that the minimum flow rate in the installation is guaranteed in all conditions. For this purpose, use the overpressure bypass valve delivered with the unit, and respect the minimum water volume.

If operation is...	Then the minimum required flow rate is...
Cooling	16 l/min
Heating/defrost	22 l/min
Domestic hot water production	



NOTICE

When circulation in each or certain space heating loops is controlled by remotely controlled valves, it is important that the minimum flow rate is guaranteed, even if all valves are closed. In case the minimum flow rate cannot be reached, a flow error 7H will be generated (no heating or operation).

See the installer reference guide for more information.

See the recommended procedure as described in "8.2 Checklist during commissioning" [p. 37].

5.4 Connecting water piping

5.4.1 To connect the water piping




NOTICE

Do NOT use excessive force when connecting the piping. Deformation of the piping can cause malfunctioning of the unit.

To facilitate service and maintenance, 2 shut-off valves and 1 overpressure bypass valve are provided. Mount the shut-off valves on the space heating water inlet and space heating water outlet. To ensure the minimum flow rate (and prevent overpressure), install the overpressure bypass valve on the space heating water outlet.

- 1 Install the shut-off valves on the space heating water pipes.
- 2 Screw the indoor unit nuts on the shut-off valve.
- 3 Connect the domestic hot water in and out pipes to the indoor unit.



- a1 Space heating/cooling – Water IN (screw connection, 1")
- a2 Space heating/cooling – Water OUT (screw connection, 1")
- b1 DHW – Cold water IN (screw connection, 3/4")
- b2 DHW – Hot water OUT (screw connection, 3/4")



NOTICE

It is recommended to install shut-off valves to domestic cold water in and domestic hot water out connections. These shut-off valves are field supplied.



NOTICE



Overpressure bypass valve (delivered as accessory). We recommend to install the overpressure bypass valve in the space heating water circuit.

- Mind the minimum water volume when choosing the installation location of the overpressure bypass valve (at the indoor unit, or at the collector). See ["5.3.1 To check the water volume and flow rate"](#) [p 16].
- Mind the minimum flow rate when adjusting the overpressure bypass valve setting. See ["5.3.1 To check the water volume and flow rate"](#) [p 16] and ["8.2.1 To check the minimum flow rate"](#) [p 38].



NOTICE

Install air purge valves at all local high points.




NOTICE

A pressure relief valve (field supply) with an opening pressure of maximum 10 bar (=1 MPa) must be installed on the domestic cold water inlet connection in accordance with the applicable legislation.

5.4.2 To connect the recirculation piping

Prerequisite: Only required if you need recirculation in your system.

- 1 Remove the top panel from the unit, see ["4.2.1 To open the indoor unit"](#) [p 13].
- 2 Cut out the rubber grommet on top of the unit, and remove the stop. The recirculation connector is placed below the hole.
- 3 Route the recirculation piping through the grommet and connect it to the recirculation connector.



- 4 Reattach the top panel.

5.4.3 To fill the water circuit

To fill the water circuit, use a field supply filling kit. Make sure you comply with the applicable legislation.



NOTICE

Pump. To prevent blocking of the pump rotor, commission the unit as quickly as possible after filling the water circuit.



INFORMATION

Make sure both air purge valves (one on the magnetic filter and one on the backup heater) are open.

5.4.4 To fill the domestic hot water tank

- 1 Open every hot water tap in turn to purge air from the system pipe work.
- 2 Open the cold water supply valve.
- 3 Close all water taps after all air is purged.
- 4 Check for water leaks.
- 5 Manually operate the field-installed pressure relief valve to ensure a free water flow through the discharge pipe.

5.4.5 To insulate the water piping

The piping in the complete water circuit **MUST** be insulated to prevent condensation during cooling operation and reduction of the heating and cooling capacity.

If the temperature is higher than 30°C and the humidity is higher than RH 80%, the thickness of the insulation materials should be at least 20 mm to prevent condensation on the surface of the insulation.

6 Electrical installation



DANGER: RISK OF ELECTROCUTION

6 Electrical installation




WARNING

ALWAYS use multicore cable for power supply cables.



WARNING

Make sure that the electrical wiring does NOT touch the refrigerant gas pipe, which can be very hot.



a Refrigerant gas pipe

6.1 About electrical compliance

Only for the backup heater of the indoor unit

See "6.3.2 To connect the backup heater power supply" [p 20].

6.2 Guidelines when connecting the electrical wiring













Tightening torques
















Indoor unit:

Item	Tightening torque (N•m)
X1M	2.45 ±10%
X2M	0.88 ±10%
X5M	0.88 ±10%
X6M	2.45 ±10%
X10M	0.88 ±10%
M4 (earth)	1.47 ±10%

6.3 Connections to the indoor unit

Item	Description
Power supply (main)	See "6.3.1 To connect the main power supply" [p 19].
Power supply (backup heater)	See "6.3.2 To connect the backup heater power supply" [p 20].
Shut-off valve	See "6.3.3 To connect the shut-off valve" [p 21].
Electricity meters	See "6.3.4 To connect the electricity meters" [p 22].
Domestic hot water pump	See "6.3.5 To connect the domestic hot water pump" [p 22].
Alarm output	See "6.3.6 To connect the alarm output" [p 23].
Space cooling/heating operation control	See "6.3.7 To connect the space cooling/heating ON/OFF output" [p 23].
Changeover to external heat source control	See "6.3.8 To connect the changeover to external heat source" [p 24].
Power consumption digital inputs	See "6.3.9 To connect the power consumption digital inputs" [p 24].
Safety thermostat	See "6.3.10 To connect the safety thermostat (normally closed contact)" [p 25].

Item	Description
Smart Grid	See "6.3.11 To connect a Smart Grid" [p 25].
Room thermostat (wired or wireless)	 See below table.  Wires: 0.75 mm ² Maximum running current: 100 mA  For the main zone: <ul style="list-style-type: none"> [2.9] Control [2.A] Thermostat type For the additional zone: <ul style="list-style-type: none"> [3.A] Thermostat type [3.9] (read-only) Control
Heat pump convector	 There are different controllers and setups possible for the heat pump convectors. Depending on the setup, you also need to implement a relay (field supply, see addendum book for optional equipment). For more information, see: <ul style="list-style-type: none"> Installation manual of the heat pump convectors Installation manual of the heat pump convector options Addendum book for optional equipment  Wires: 0.75 mm ² Maximum running current: 100 mA  For the main zone: <ul style="list-style-type: none"> [2.9] Control [2.A] Thermostat type For the additional zone: <ul style="list-style-type: none"> [3.A] Thermostat type [3.9] (read-only) Control
Remote outdoor sensor	 See: <ul style="list-style-type: none"> Installation manual of the remote outdoor sensor Addendum book for optional equipment  Wires: 2×0.75 mm ²  [9.B.1]=1 (External sensor = Outdoor) [9.B.2] Ext. amb. sensor offset [9.B.3] Averaging time
Remote indoor sensor	 See: <ul style="list-style-type: none"> Installation manual of the remote indoor sensor Addendum book for optional equipment  Wires: 2×0.75 mm ²  [9.B.1]=2 (External sensor = Room) [1.7] Room sensor offset

Item	Description
Human Comfort Interface	 See: <ul style="list-style-type: none"> Installation and operation manual of the Human Comfort Interface Addendum book for optional equipment
	 Wires: 2×(0.75~1.25 mm ²) Maximum length: 500 m
	 [2.9] Control [1.6] Room sensor offset
LAN adapter	 See: <ul style="list-style-type: none"> Installation manual of the LAN adapter Addendum book for optional equipment
	 Wires: 2×(0.75~1.25 mm ²). Must be sheathed. Maximum length: 200 m
	 See installation manual of the LAN adapter
WLAN cartridge	 See: <ul style="list-style-type: none"> Installation manual of the WLAN cartridge Installer reference guide
	 —
	 [D] Wireless gateway
WLAN module	 See: <ul style="list-style-type: none"> Installation manual of the WLAN module Addendum book for optional equipment Installer reference guide
	 Use the cable delivered with the WLAN module.
	 [D] Wireless gateway
Bizone kit	 See: <ul style="list-style-type: none"> Installation manual of the bizone kit Addendum book for optional equipment
	 Use the cable delivered with the bizone kit.
	 [9.P] Bizone kit



for room thermostat (wired or wireless):


In case of...	See...
Wireless room thermostat	<ul style="list-style-type: none"> Installation manual of the wireless room thermostat Addendum book for optional equipment
Wired room thermostat without multi-zoning base unit	<ul style="list-style-type: none"> Installation manual of the wired room thermostat Addendum book for optional equipment

In case of...	See...
Wired room thermostat with multi-zoning base unit	<ul style="list-style-type: none"> Installation manual of the wired room thermostat (digital or analogue) + multi-zoning base unit Addendum book for optional equipment In this case: <ul style="list-style-type: none"> You need to connect the wired room thermostat (digital or analogue) to the multi-zoning base unit You need to connect the multi-zoning base unit to the outdoor unit For cooling/heating operation, you also need to implement a relay (field supply, see addendum book for optional equipment)

6.3.1 To connect the main power supply



- Open the following (see "4.2.1 To open the indoor unit" ▶ 13):


1	Top panel
2	User interface panel
3	Upper switch box cover




- Connect the main power supply.

In case of normal kWh rate power supply

 Interconnection cable (= main power supply)	Wires: (3+GND)×1.5 mm ²
 —	



6 Electrical installation





a Interconnection cable (=main power supply)

In case of preferential kWh rate power supply

	Interconnection cable (= main power supply)	Wires: (3+GND)×1.5 mm ²
	Normal kWh rate power supply	Wires: 1N Maximum running current: 6.3 A
	Preferential kWh rate power supply contact	Wires: 2×(0.75~1.25 mm ²) Maximum length: 50 m. Preferential kWh rate power supply contact: 16 V DC detection (voltage supplied by PCB). The voltage-free contact shall ensure the minimum applicable load of 15 V DC, 10 mA.
	[9.8] Benefit kWh power supply	

Connect X11Y to X11YB.



a Interconnection cable (=main power supply)

b Normal kWh rate power supply

c Preferential power supply contact

3 Fix the cables with cable ties to the cable tie mountings.



INFORMATION

In case of preferential kWh rate power supply, connect X11Y to X11YB. The necessity of separate normal kWh rate power supply to indoor unit (b) X2M/5+6 depends on the type of preferential kWh rate power supply.

Separate connection to the indoor unit is required:

- if preferential kWh rate power supply is interrupted when active, OR
- if no power consumption of the indoor unit is allowed at the preferential kWh rate power supply when active.

6.3.2 To connect the backup heater power supply

	Backup heater type	Power supply	Wires
	*6V	1N~ 230 V (6V3)	2+GND
		3~ 230 V (6T1)	3+GND
	*9W	3N~ 400 V	4+GND
	[9.3] Backup heater		



WARNING

The backup heater **MUST** have a dedicated power supply and **MUST** be protected by the safety devices required by the applicable legislation.



CAUTION

To guarantee the unit is completely earthed, **ALWAYS** connect the backup heater power supply and the earth cable.

The backup heater capacity can vary, depending on the indoor unit model. Make sure that the power supply is in accordance with the backup heater capacity, as listed in the table below.

Backup heater type	Backup heater capacity	Power supply	Maximum running current	Z _{max}
*6V	2 kW	1N~ 230 V ^(a)	9 A	—
	4 kW	1N~ 230 V ^(a)	17 A ^{(b)(c)}	0.22 Ω
	6 kW	1N~ 230 V ^(a)	26 A ^{(b)(c)}	0.22 Ω
	2 kW	3~ 230 V ^(d)	5 A	—
	4 kW	3~ 230 V ^(d)	10 A	—
	6 kW	3~ 230 V ^(d)	15 A	—

Backup heater type	Backup heater capacity	Power supply	Maximum running current	Z_{max}
*9W	3 kW	3N~ 400 V	4 A	—
	6 kW	3N~ 400 V	9 A	—
	9 kW	3N~ 400 V	13 A	—


(a) 6V3

(b) Electrical equipment complying with EN/IEC 61000-3-12 (European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input current >16 A and ≤75 A per phase).



(c) This equipment complies with EN/IEC 61000-3-11 (European/International Technical Standard setting the limits for voltage changes, voltage fluctuations and flicker in public low-voltage supply systems for equipment with rated current ≤75 A) provided that the system impedance Z_{sys} is less than or equal to Z_{max} at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a system impedance Z_{sys} less than or equal to Z_{max} .

(d) 6T1

Connect the backup heater power supply as follows:



- a Factory-mounted cable connected to the contactor of the backup heater, inside the switch box (K5M)
b Field wiring (see table below)



- F1B** Overcurrent fuse (field supply). Recommended fuse: 4-pole; 20 A; curve 400 V; tripping class C.
K5M Safety contactor (in the lower switch box)
Q1DI Earth leakage circuit breaker (field supply)
SWB Switch box
X6M Terminal (field supply)



NOTICE

Do NOT cut or remove the backup heater power supply cable.

6.3.3 To connect the shut-off valve



INFORMATION

Shut-off valve usage example. In case of one LWT zone, and a combination of underfloor heating and heat pump convectors, install a shut-off valve before the underfloor heating to prevent condensation on the floor during cooling operation. For more information, see the installer reference guide.



Wires: 2×0.75 mm²

Maximum running current: 100 mA

230 V AC supplied by PCB




[2.D] Shut off valve

- 1 Open the following (see "4.2.1 To open the indoor unit" ▶ 13):

6 Electrical installation

1	Top panel
2	User interface panel
3	Upper switch box cover





- 2 Connect the valve control cable to the appropriate terminals as shown in the illustration below.



NOTICE

Wiring is different for a NC (normally closed) valve and a NO (normally open) valve.



- 3 Fix the cable with cable ties to the cable tie mountings.

6.3.4 To connect the electricity meters

	Wires: 2 (per meter)×0.75 mm ²
	Electricity meters: 12 V DC pulse detection (voltage supplied by PCB)
	[9.A] Energy metering




INFORMATION




In case of an electricity meter with transistor output, check the polarity. The positive polarity **MUST** be connected to X5M/6 and X5M/4; the negative polarity to X5M/5 and X5M/3.

- 1 Open the following (see "4.2.1 To open the indoor unit" ▶ 13):

1	Top panel
2	User interface panel
3	Upper switch box cover



- 2 Connect the electricity meters cable to the appropriate terminals as shown in the illustration below.




- 3 Fix the cable with cable ties to the cable tie mountings.

6.3.5 To connect the domestic hot water pump



	Wires: (2+GND)×0.75 mm ²
	DHW pump output. Maximum load: 2 A (inrush), 230 V AC, 1 A (continuous)
	[9.2.2] DHW pump [9.2.3] DHW pump schedule

- 1 Open the following (see "4.2.1 To open the indoor unit" ▶ 13):

1	Top panel
2	User interface panel
3	Upper switch box cover



- 2 Connect the domestic hot water pump cable to the appropriate terminals as shown in the illustration below.



3 Fix the cable with cable ties to the cable tie mountings.




6.3.6 To connect the alarm output

	Wires: (2+1)×0.75 mm ²
	Maximum load: 0.3 A, 250 V AC
	[9.D] Alarm output

1 Open the following (see "4.2.1 To open the indoor unit" ▶ 13):

1	Top panel
2	User interface panel
3	Upper switch box cover

2 Connect the alarm output cable to the appropriate terminals as shown in the illustration below.



- a Installation of EKR1HBAA is required.
- b Prewiring between X2M/7+9 and Q1L (= thermal protector backup heater). Do NOT change.

3 Fix the cable with cable ties to the cable tie mountings.

6.3.7 To connect the space cooling/heating ON/OFF output



INFORMATION

Cooling is only applicable in case of:

- Reversible models
- Heating only models + conversion kit (EKHVCONV*)




	Wires: (2+1)×0.75 mm ²
	Maximum load: 0.3 A, 250 V AC
	—

1 Open the following (see "4.2.1 To open the indoor unit" ▶ 13):

1	Top panel
2	User interface panel
3	Upper switch box cover

2 Connect the space cooling/heating ON/OFF output cable to the appropriate terminals as shown in the illustration below.

6 Electrical installation



- a** Installation of EKR1HBAA is required.
- b** Rewiring between X2M/7+9 and Q1L (= thermal protector backup heater). Do NOT change.

- 3** Fix the cable with cable ties to the cable tie mountings.




6.3.8 To connect the changeover to external heat source

	Wires: 2×0.75 mm ²
	Maximum load: 0.3 A, 250 V AC
	Minimum load: 20 mA, 5 V DC
	[9.C] Bivalent

- 1** Open the following (see "4.2.1 To open the indoor unit" [p 13]):

1 Top panel	
2 User interface panel	
3 Upper switch box cover	

- 2** Connect the changeover to external heat source cable to the appropriate terminals as shown in the illustration below.



- a** Installation of EKR1HBAA is required.

- 3** Fix the cable with cable ties to the cable tie mountings.



6.3.9 To connect the power consumption digital inputs

	Wires: 2 (per input signal)×0.75 mm ²
	Power limitation digital inputs: 12 V DC / 12 mA detection (voltage supplied by PCB)
	[9.9] Power consumption control.

- 1** Open the following (see "4.2.1 To open the indoor unit" [p 13]):

1 Top panel	
2 User interface panel	
3 Upper switch box cover	

- 2** Connect the power consumption digital inputs cable to the appropriate terminals as shown in the illustration below.



a Installation of EKR1AHTA is required.


- 3 Fix the cable with cable ties to the cable tie mountings.

6.3.10 To connect the safety thermostat (normally closed contact)

	Wires: 2×0.75 mm ² Maximum length: 50 m Safety thermostat contact: 16 V DC detection (voltage supplied by PCB). The voltage-free contact shall ensure the minimum applicable load of 15 V DC, 10 mA.
	—



- 1 Open the following (see "4.2.1 To open the indoor unit" ▶ 13):

1	Top panel
2	User interface panel
3	Upper switch box cover



- 2 Connect the safety thermostat (normally closed) cable to the appropriate terminals as shown in the illustration below.

Note: The jumper wire (factory-mounted) must be removed from the respective terminals.



- 3 Fix the cable with cable ties to the cable tie mountings.



NOTICE

Make sure to select and install the safety thermostat according to the applicable legislation.

In any case, to prevent unnecessary tripping of the safety thermostat, we recommend the following:

- The safety thermostat is automatically resettable.
- The safety thermostat has a maximum temperature variation rate of 2°C/min.
- There is a minimum distance of 2 m between the safety thermostat and the 3-way valve.



NOTICE

Error. If you remove the jumper (open circuit) but do NOT connect the safety thermostat, stop error 8H-03 will occur.

6.3.11 To connect a Smart Grid

This topic describes 2 possible ways to connect the indoor unit to a Smart Grid:

- In case of low voltage Smart Grid contacts
- In case of high voltage Smart Grid contacts. This requires the installation of the Smart Grid relay kit (EKRELSG).

The 2 incoming Smart Grid contacts can activate the following Smart Grid modes:



Smart Grid contact		Smart Grid operation mode
1	2	
0	0	Free running
0	1	Forced off
1	0	Recommended on
1	1	Forced on

6 Electrical installation


The use of a Smart Grid pulse meter is not mandatory:

If Smart Grid pulse meter is...	Then [9.8.8] Limit setting kW is...
Used ([9.A.2] Electricity meter 2 ≠ None)	Not applicable
Not used ([9.A.2] Electricity meter 2 = None)	Applicable

In case of low voltage Smart Grid contacts

	Wires (Smart Grid pulse meter): 0.5 mm ²
	Wires (low voltage Smart Grid contacts): 0.5 mm ²
	[9.8.4]=3 (Benefit kWh power supply = Smart grid)
	[9.8.5] Smart grid operation mode
	[9.8.6] Allow electrical heaters
	[9.8.7] Enable room buffering
	[9.8.8] Limit setting kW

The wiring of the Smart Grid in case of low voltage contacts is as follows:





a Jumper (factory-mounted). If you also connect a safety thermostat (Q4L), replace the jumper with the safety thermostat wires.

- S4S Smart Grid pulse meter
 ①/S10S Low voltage Smart Grid contact 1
 ②/S11S Low voltage Smart Grid contact 2

1 Open the following (see "4.2.1 To open the indoor unit" ► 13):



1	Top panel
2	User interface panel
3	Upper switch box cover

2 Connect the wiring as follows:




3 Fix the cables with cable ties to the cable tie mountings.

In case of high voltage Smart Grid contacts

	Wires (Smart Grid pulse meter): 0.5 mm ²
	Wires (high voltage Smart Grid contacts): 1 mm ²
	[9.8.4]=3 (Benefit kWh power supply = Smart grid)
	[9.8.5] Smart grid operation mode
	[9.8.6] Allow electrical heaters
	[9.8.7] Enable room buffering
	[9.8.8] Limit setting kW

The wiring of the Smart Grid in case of high voltage contacts is as follows:



STEP 1 Smart Grid relay kit installation

STEP 2 Low voltage connections

STEP 3 High voltage connections

① High voltage Smart Grid contact 1

② High voltage Smart Grid contact 2


a, b Coil sides of relays

c, d Contact sides of relays

e Jumper (factory-mounted). If you also connect a safety thermostat (Q4L), replace the jumper with the safety thermostat wires.

f Smart Grid pulse meter

1 Install the components of the Smart Grid relay kit as follows:



K1A, K2A Relays

X10M Terminal block


a Screws for X10M

b Screws for K1A and K2A



c Sticker to put on the high voltage wires

d Wires between the relays and X5M (AWG22 ORG)


e Wires between the relays and X10M (AWG18 RED)




2 Connect the low voltage wiring as follows:



3 Connect the high voltage wiring as follows:




- 1 High voltage Smart Grid contact 1
- 2 High voltage Smart Grid contact 2



4 Fix the cables with cable ties to the cable tie mountings. If necessary, bundle excessive cable length with a cable tie.

6.4 After connecting the electrical wiring to the indoor unit

To prevent water ingress to the switch box, seal the low voltage wiring intake using the sealing tape (delivered as accessory).



7 Configuration



INFORMATION

Cooling is only applicable in case of:

- Reversible models
- Heating only models + conversion kit (EKHVCONV*)

7.1 Overview: Configuration

This chapter describes what you have to do and know to configure the system after it is installed.



NOTICE

This chapter explains only the basic configuration. For more detailed explanation and background information, see the installer reference guide.

Why

If you do NOT configure the system correctly, it might NOT work as expected. The configuration influences the following:

- The calculations of the software
- What you can see on and do with the user interface

How

You can configure the system via the user interface.

- **First time – Configuration wizard.** When you turn ON the user interface for the first time (via the unit), the configuration wizard starts to help you configure the system.

7 Configuration

- **Restart the configuration wizard.** If the system is already configured, you can restart the configuration wizard. To restart the configuration wizard, go to Installer settings > Configuration wizard. To access Installer settings, see ["7.1.1 To access the most used commands" \[p 28\]](#).
- **Afterwards.** If necessary, you can make changes to the configuration in the menu structure or the overview settings.



INFORMATION

When the configuration wizard is finished, the user interface will show an overview screen and request to confirm. When confirmed, the system will restart and the home screen will be displayed.

Accessing settings – Legend for tables

You can access the installer settings using two different methods. However, NOT all settings are accessible via both methods. If so, the corresponding table columns in this chapter are set to N/A (not applicable).

Method	Column in tables
Accessing settings via the breadcrumb in the home menu screen or the menu structure . To enable breadcrumbs, press the ? button in the home screen.	# For example: [2.9]
Accessing settings via the code in the overview field settings .	Code For example: [C-07]

See also:

- ["To access the installer settings" \[p 28\]](#)
- ["7.5 Menu structure: Overview installer settings" \[p 36\]](#)

7.1.1 To access the most used commands


To change the user permission level

You can change the user permission level as follows:

1	Go to [B]: User profile.	
2	Enter the applicable pin code for the user permission level.	—
	▪ Browse through the list of digits and change the selected digit.	
	▪ Move the cursor from left to right.	
	▪ Confirm the pin code and proceed.	


Installer pin code

The Installer pin code is **5678**. Additional menu items and installer settings are now available.




Advanced user pin code

The Advanced user pin code is **1234**. Additional menu items for the user are now visible.



User pin code

The User pin code is **0000**.



To access the installer settings

- 1 Set the user permission level to Installer.
- 2 Go to [9]: Installer settings.

To modify an overview setting

Example: Modify [1-01] from 15 to 20.

Most settings can be configured via the menu structure. If for any reason it is required to change a setting using the overview settings, then the overview settings can be accessed as follows:

1	Set the user permission level to Installer. See "To change the user permission level" [p 28] .	—
2	Go to [9.I]: Installer settings > Overview field settings.	
3	Turn the left dial to select the first part of the setting and confirm by pressing the dial.	
4	Turn the left dial to select the second part of the setting	
5	Turn the right dial to modify the value from 15 to 20.	
6	Press the left dial to confirm the new setting.	
7	Press the center button to go back to the home screen.	



INFORMATION

When you change the overview settings and you go back to the home screen, the user interface will show a popup screen and request to restart the system.

When confirmed, the system will restart and recent changes will be applied.

7.2 Configuration wizard

After first power ON of the system, the user interface will guide you using the configuration wizard. This way you can set the most important initial settings. This way the unit will be able to run properly. Afterwards, more detailed settings can be done via the menu structure if required.

Protective functions

The unit is equipped with the following protective functions:

- Room antifrost [2-06]
- Tank disinfection [2-01]

The unit automatically runs the protective functions when necessary. During installation or service, this behaviour is undesired. Therefore, the protective functions can be disabled. For more information, see the Installer reference guide, chapter Configuration.

7.2.1 Configuration wizard: Language

#	Code	Description
[7.1]	N/A	Language

7.2.2 Configuration wizard: Time and date

#	Code	Description
[7.2]	N/A	Set the local time and date



INFORMATION

By default, daylight savings time is enabled and clock format is set to 24 hours. These settings can be changed during initial configuration or via the menu structure [7.2]: User settings > Time/date.

7.2.3 Configuration wizard: System

Indoor unit type

The indoor unit type is displayed, but cannot be adjusted.

Backup heater type

The backup heater is adapted to be connected to most common European electricity grids. The type of backup heater can be viewed but not changed.

#	Code	Description
[9.3.1]	[E-03]	<ul style="list-style-type: none"> ▪ 3: 6V ▪ 4: 9V

Domestic hot water

The following setting determines if the system can prepare domestic hot water or not, and which tank is used. This setting is read only.

#	Code	Description
[9.2.1]	[E-05] ^(a) [E-06] ^(a) [E-07] ^(a)	<ul style="list-style-type: none"> ▪ Integrated The backup heater will also be used for domestic hot water heating.

- ^(a) Use the menu structure instead of the overview settings. Menu structure setting [9.2.1] replaces the following 3 overview settings:
- [E-05]: Can the system prepare domestic hot water?
 - [E-06]: Is a domestic hot water tank installed in the system?
 - [E-07]: What kind of domestic hot water tank is installed?

Emergency

When the heat pump fails to operate, the backup heater can serve as an emergency heater. It then takes over the heat load either automatically or by manual interaction.

- When Emergency is set to Automatic and a heat pump failure occurs, the backup heater automatically takes over the domestic hot water production and space heating.
- When Emergency is set to Manual and a heat pump failure occurs, the domestic hot water heating and space heating stops.

To manually recover it via the user interface, go to the Malfunctioning main menu screen and confirm whether the backup heater can take over the heat load or not.

- Alternatively, when Emergency is set to:
 - auto SH reduced/DHW on, space heating is reduced but domestic hot water is still available.
 - auto SH reduced/DHW off, space heating is reduced and domestic hot water is NOT available.
 - auto SH normal/DHW off, space heating operates as normally but domestic hot water is NOT available.

Similarly as in Manual mode, the unit can take the full load with the backup heater if the user activates this via the Malfunctioning main menu screen.

To keep energy consumption low, we recommend to set Emergency to auto SH reduced/DHW off if the house is unattended for longer periods.

#	Code	Description
[9.5.1]	[4-06]	<ul style="list-style-type: none"> ▪ 0: Manual ▪ 1: Automatic ▪ 2: auto SH reduced/DHW on ▪ 3: auto SH reduced/DHW off ▪ 4: auto SH normal/DHW off



INFORMATION

The auto emergency setting can be set in the menu structure of the user interface only.



INFORMATION

If a heat pump failure occurs and Emergency is not set to Automatic (setting 1), the room frost protection function and the underfloor heating screed dryout function will remain active even if the user does NOT confirm emergency operation.


Number of zones

The system can supply leaving water to up to 2 water temperature zones. During configuration, the number of water zones must be set.




INFORMATION

Mixing station. If your system layout contains 2 LWT zones, you need to install a mixing station in front of the main LWT zone.

#	Code	Description
[4.4]	[7-02]	<ul style="list-style-type: none"> ▪ 0: Single zone <p>Only one leaving water temperature zone:</p>  <p>a Main LWT zone</p>

7 Configuration

#	Code	Description
[4.4]	[7-02]	<ul style="list-style-type: none"> 1: Dual zone <p>Two leaving water temperature zones. The main leaving water temperature zone consists of the higher load heat emitters and a mixing station to achieve the desired leaving water temperature. In heating:</p>  <p>a Additional LWT zone: Highest temperature b Main LWT zone: Lowest temperature c Mixing station</p>



NOTICE

NOT configuring the system in the following way can cause damage to the heat emitters. If there are 2 zones, it is important that in heating:

- the zone with the lowest water temperature is configured as the main zone, and
- the zone with the highest water temperature is configured as the additional zone.



NOTICE

If there are 2 zones and the emitter types are wrongly configured, water of high temperature can be sent towards a low temperature emitter (underfloor heating). To avoid this:

- Install an aquastat/thermostatic valve to avoid too high temperatures towards a low temperature emitter.
- Make sure you set the emitter types for the main zone [2.7] and for the additional zone [3.7] correctly in accordance with the connected emitter.



NOTICE

An overpressure bypass valve can be integrated in the system. Keep in mind that this valve might not be shown on the illustrations.

7.2.4 Configuration wizard: Backup heater

The backup heater is adapted to be connected to most common European electricity grids. If the backup heater is available, the voltage, configuration and capacity must be set on the user interface.

The capacities for the different steps of the backup heater must be set for the energy metering and/or power consumption control feature to work properly. When measuring the resistance value of each heater, you can set the exact heater capacity and this will lead to more accurate energy data.

Backup heater type

The backup heater is adapted to be connected to most common European electricity grids. The type of backup heater can be viewed but not changed.

#	Code	Description
[9.3.1]	[E-03]	<ul style="list-style-type: none"> 3: 6V 4: 9W

Voltage

- For a 6V model, this can be set to:
 - 230V, 1ph
 - 230V, 3ph
- For a 9W model, this is fixed to 400V, 3ph.

#	Code	Description
[9.3.2]	[5-0D]	<ul style="list-style-type: none"> 0: 230V, 1ph 1: 230V, 3ph 2: 400V, 3ph

Configuration

The backup heater can be configured in different ways. It can be chosen to have a 1-step only backup heater or a backup heater with 2 steps. If 2 steps, the capacity of the second step depends on this setting. It can also be chosen to have a higher capacity of the second step in emergency.

#	Code	Description
[9.3.3]	[4-0A]	<ul style="list-style-type: none"> 0: Relay 1 1: Relay 1 / Relay 1+2 2: Relay 1 / Relay 2 3: Relay 1 / Relay 2 Emergency Relay 1+2



INFORMATION

Settings [9.3.3] and [9.3.5] are linked. Changing one setting influences the other. If you change one, check if the other is still as expected.



INFORMATION

During normal operation, the capacity of the second step of the backup heater at nominal voltage is equal to [6-03]+[6-04].



INFORMATION

If [4-0A]=3 and emergency mode is active, the power usage of the backup heater is maximal and equal to $2 \times [6-03] + [6-04]$.



INFORMATION

Only for systems with integrated domestic hot water tank: If the storage temperature setpoint is higher than 50°C, Daikin recommends NOT to disable the backup heater second step because it will have a big impact on the required time for the unit to heat up the domestic hot water tank.

Capacity step 1

#	Code	Description
[9.3.4]	[6-03]	<ul style="list-style-type: none"> The capacity of the first step of the backup heater at nominal voltage.

Additional capacity step 2

#	Code	Description
[9.3.5]	[6-04]	<ul style="list-style-type: none"> The capacity difference between the second and first step of the backup heater at nominal voltage. Nominal value depends on backup heater configuration.

7.2.5 Configuration wizard: Main zone

The most important settings for the main leaving water zone can be set here.

Emitter type

Heating up or cooling down the main zone can take longer. This depends on:

- The water volume of the system
- The heater emitter type of the main zone

The setting Emitter type can compensate for a slow or a quick heating/cooling system during the heat up/cool down cycle. In room thermostat control, Emitter type influences the maximum modulation of the desired leaving water temperature, and the possibility for usage of the automatic cooling/heating changeover based on the indoor ambient temperature.

It is important to set Emitter type correctly and in accordance with your system layout. The target delta T for the main zone depends on it.

#	Code	Description
[2.7]	[2-0C]	<ul style="list-style-type: none"> ▪ 0: Underfloor heating ▪ 1: Fancoil unit ▪ 2: Radiator

The setting of the emitter type has an influence on the space heating setpoint range and the target delta T in heating as follows:

Description	Space heating setpoint range	Target delta T in heating
0: Underfloor heating	Maximum 55°C	Variable
1: Fancoil unit	Maximum 55°C	Variable
2: Radiator	Maximum 60°C	Fixed 8°C



NOTICE

Average emitter temperature = Leaving water temperature – (Delta T)/2

This means that for a same leaving water temperature setpoint, the average emitter temperature of radiators is lower than that of underfloor heating because of a bigger delta T.

Example radiators: $40 - 8/2 = 36^\circ\text{C}$

Example underfloor heating: $40 - 5/2 = 37.5^\circ\text{C}$

To compensate, you can:

- Increase the weather-dependent curve desired temperatures [2.5].
- Enable leaving water temperature modulation and increase the maximum modulation [2.C].

Control

Define how the operation of the unit is controlled.

Control	In this control...
Leaving water	Unit operation is decided based on the leaving water temperature regardless the actual room temperature and/or heating or cooling demand of the room.
External room thermostat	Unit operation is decided by the external thermostat or equivalent (e.g. heat pump convector).
Room thermostat	Unit operation is decided based on the ambient temperature of the dedicated Human Comfort Interface (BRC1HHDA used as room thermostat).

#	Code	Description
[2.9]	[C-07]	<ul style="list-style-type: none"> ▪ 0: Leaving water ▪ 1: External room thermostat ▪ 2: Room thermostat

Setpoint mode

Define the setpoint mode:

- Fixed: the desired leaving water temperature does not depend on the outdoor ambient temperature.
- In WD heating, fixed cooling mode, the desired leaving water temperature:
 - depends on the outdoor ambient temperature for heating
 - does NOT depend on the outdoor ambient temperature for cooling
- In Weather dependent mode, the desired leaving water temperature depends on the outdoor ambient temperature.

#	Code	Description
[2.4]	N/A	Setpoint mode: <ul style="list-style-type: none"> ▪ Fixed ▪ WD heating, fixed cooling ▪ Weather dependent

When weather dependent operation is active, low outdoor temperatures will result in warmer water and vice versa. During weather dependent operation, the user can shift the water temperature up or down by a maximum of 10°C.

Schedule

Indicates if the desired leaving water temperature is according to a schedule. Influence of the LWT setpoint mode [2.4] is as follows:

- In Fixed LWT setpoint mode, the scheduled actions consist of desired leaving water temperatures, either preset or custom.
- In Weather dependent LWT setpoint mode, the scheduled actions consist of desired shift actions, either preset or custom.

#	Code	Description
[2.1]	N/A	<ul style="list-style-type: none"> ▪ 0: No ▪ 1: Yes

7.2.6 Configuration wizard: Additional zone

The most important settings for the additional leaving water zone can be set here.

Emitter type

For more info about this functionality, see ["7.2.5 Configuration wizard: Main zone"](#) ▶ 31].

#	Code	Description
[3.7]	[2-0D]	<ul style="list-style-type: none"> ▪ 0: Underfloor heating ▪ 1: Fancoil unit ▪ 2: Radiator

Control

The control type is displayed here, but cannot be adjusted. It is determined by the control type of the main zone. For more info about the functionality, see ["7.2.5 Configuration wizard: Main zone"](#) ▶ 31].

7 Configuration

#	Code	Description
[3.9]	N/A	<ul style="list-style-type: none">0: Leaving water if the control type of the main zone is Leaving water.1: External room thermostat if the control type of the main zone is External room thermostat or Room thermostat.

Setpoint mode

For more info about this functionality, see ["7.2.5 Configuration wizard: Main zone" \[31\]](#).

#	Code	Description
[3.4]	N/A	<ul style="list-style-type: none">0: Fixed1: WD heating, fixed cooling2: Weather dependent

If you choose WD heating, fixed cooling or Weather dependent, the next screen will be the detailed screen with weather-dependent curves. Also see ["7.3 Weather-dependent curve" \[32\]](#).

Schedule

Indicates if the desired leaving water temperature is according to a schedule. Also see ["7.2.5 Configuration wizard: Main zone" \[31\]](#).

#	Code	Description
[3.1]	N/A	<ul style="list-style-type: none">0: No1: Yes

7.2.7 Configuration wizard: Tank



INFORMATION

To make tank defrost possible, we recommend a minimum tank temperature of 35°C.

Heat up mode

The domestic hot water can be prepared in 3 different ways. They differ from each other by the way the desired tank temperature is set and how the unit acts upon it.

#	Code	Description
[5.6]	[6-0D]	Heat up mode: <ul style="list-style-type: none">0: Reheat only: Only reheat operation is allowed.1: Schedule + reheat: The domestic hot water tank is heated according to a schedule and between the scheduled heat up cycles, reheat operation is allowed.2: Schedule only: The domestic hot water tank can ONLY be heated according to a schedule.

See the operation manual for more details.

Comfort setpoint

Only applicable when domestic hot water preparation is Schedule only or Schedule + reheat. When programming the schedule, you can make use of the comfort setpoint as a preset value. When you later want to change the storage setpoint, you only have to do it in one place.

The tank will heat up until the **storage comfort temperature** has been reached. It is the higher desired temperature when a storage comfort action is scheduled.

Additionally, a storage stop can be programmed. This feature puts a stop to tank heating even if the setpoint has NOT been reached. Only program a storage stop when tank heating is absolutely undesirable.

#	Code	Description
[5.2]	[6-0A]	Comfort setpoint: <ul style="list-style-type: none">30°C~[6-0E]°C

Eco setpoint

The **storage economic temperature** denotes the lower desired tank temperature. It is the desired temperature when a storage economic action is scheduled (preferably during day).

#	Code	Description
[5.3]	[6-0B]	Eco setpoint: <ul style="list-style-type: none">30°C~min(50,[6-0E])°C

Reheat setpoint

Desired reheat tank temperature, used:

- in Schedule + reheat mode, during reheat mode: the guaranteed minimum tank temperature is set by the Reheat setpoint minus the reheat hysteresis. If the tank temperature drops below this value, the tank is heated up.
- during storage comfort, to prioritize the domestic hot water preparation. When the tank temperature rises above this value, domestic hot water preparation and space heating/cooling are executed sequentially.

#	Code	Description
[5.4]	[6-0C]	Reheat setpoint: <ul style="list-style-type: none">30°C~min(50,[6-0E])°C

7.3 Weather-dependent curve

7.3.1 What is a weather-dependent curve?

Weather-dependent operation

The unit operates 'weather dependent' if the desired leaving water or tank temperature is determined automatically by the outdoor temperature. It therefore is connected to a temperature sensor on the North wall of the building. If the outdoor temperature drops or rises, the unit compensates instantly. Thus, the unit does not have to wait for feedback by the thermostat to increase or decrease the temperature of the leaving water or tank. Because it reacts more quickly, it prevents high rises and drops of the indoor temperature and water temperature at tap points.

Advantage

Weather-dependent operation reduces energy consumption.

Weather-dependent curve

To be able to compensate for differences in temperature, the unit relies on its weather-dependent curve. This curve defines how much the temperature of the tank or leaving water must be at different outdoor temperatures. Because the slope of the curve depends on local circumstances such as climate and the insulation of the house, the curve can be adjusted by an installer or user.

Types of weather-dependent curve

There are 2 types of weather-dependent curves:

- 2-points curve
- Slope-offset curve

Which type of curve you use to make adjustments, depends on your personal preference. See ["7.3.4 Using weather-dependent curves" \[34\]](#).

Availability

The weather-dependent curve is available for:

- Main zone - Heating
- Main zone - Cooling

- Additional zone - Heating
- Additional zone - Cooling
- Tank (only available to installers)



INFORMATION


To operate weather dependent, correctly configure the setpoint of the main zone, additional zone or tank. See "7.3.4 Using weather-dependent curves" [p. 34].

7.3.2 2-points curve

Define the weather-dependent curve with these two setpoints:

- Setpoint (X1, Y2)
- Setpoint (X2, Y1)

Example



Item	Description
a	Selected weather dependent zone: <ul style="list-style-type: none"> ☀: Main zone or additional zone heating ❄: Main zone or additional zone cooling 🏠: Domestic hot water
X1, X2	Examples of outdoor ambient temperature
Y1, Y2	Examples of desired tank temperature or leaving water temperature. The icon corresponds to the heat emitter for that zone: <ul style="list-style-type: none"> 🏠: Underfloor heating 📄: Fan coil unit 🔥: Radiator 🏠: Domestic hot water tank

Possible actions on this screen	
🔍⋯⋯○	Go through the temperatures.
○⋯⋯🔍	Change the temperature.
○⋯⋯🏠	Go to the next temperature.
🏠⋯⋯○	Confirm changes and proceed.

7.3.3 Slope-offset curve

Slope and offset


Define the weather-dependent curve by its slope and offset:

- Change the **slope** to differently increase or decrease the temperature of the leaving water for different ambient temperatures. For example, if leaving water temperature is in general fine but at low ambient temperatures too cold, raise the slope so that leaving water temperature is heated increasingly more at decreasingly lower ambient temperatures.
- Change the **offset** to equally increase or decrease the temperature of the leaving water for different ambient temperatures. For example, if leaving water temperature is always


a bit too cold at different ambient temperatures, shift the offset up to equally increase the leaving water temperature for all ambient temperatures.

Examples

Weather-dependent curve when slope is selected:



Weather-dependent curve when offset is selected:



Item	Description
a	WD curve before changes.
b	WD curve after changes (as example): <ul style="list-style-type: none"> ▪ When slope is changed, the new preferred temperature at X1 is unequally higher than the preferred temperature at X2. ▪ When offset is changed, the new preferred temperature at X1 is equally higher as the preferred temperature at X2.
c	Slope
d	Offset
e	Selected weather dependent zone: <ul style="list-style-type: none"> ☀: Main zone or additional zone heating ❄: Main zone or additional zone cooling 🏠: Domestic hot water
X1, X2	Examples of outdoor ambient temperature
Y1, Y2, Y3, Y4	Examples of desired tank temperature or leaving water temperature. The icon corresponds to the heat emitter for that zone: <ul style="list-style-type: none"> 🏠: Underfloor heating 📄: Fan coil unit 🔥: Radiator 🏠: Domestic hot water tank

Possible actions on this screen	
🔍⋯⋯○	Select slope or offset.
○⋯⋯🔍	Increase or decrease the slope/offset.
○⋯⋯🏠	When slope is selected: set slope and go to offset. When offset is selected: set offset.
🏠⋯⋯○	Confirm changes and return to the submenu.

7 Configuration

7.3.4 Using weather-dependent curves

Configure weather-dependent curves as following:

To define the setpoint mode

To use the weather-dependent curve, you need to define the correct setpoint mode:

Go to setpoint mode ...	Set the setpoint mode to ...
Main zone – Heating	
[2.4] Main zone > Setpoint mode	WD heating, fixed cooling OR Weather dependent
Main zone – Cooling	
[2.4] Main zone > Setpoint mode	Weather dependent
Additional zone – Heating	
[3.4] Additional zone > Setpoint mode	WD heating, fixed cooling OR Weather dependent
Additional zone – Cooling	
[3.4] Additional zone > Setpoint mode	Weather dependent
Tank	
[5.B] Tank > Setpoint mode	Restriction: Only available to installers. Weather dependent

To change the type of weather-dependent curve

To change the type for all zones (main + additional) and for the tank, go to [2.E] Main zone > WD curve type.

Viewing which type is selected is also possible via:

- [3.C] Additional zone > WD curve type
- [5.E] Tank > WD curve type

Restriction: Only available to installers.

To change the weather-dependent curve

Zone	Go to ...
Main zone – Heating	[2.5] Main zone > Heating WD curve
Main zone – Cooling	[2.6] Main zone > Cooling WD curve
Additional zone – Heating	[3.5] Additional zone > Heating WD curve
Additional zone – Cooling	[3.6] Additional zone > Cooling WD curve
Tank	Restriction: Only available to installers. [5.C] Tank > WD curve



INFORMATION

Maximum and minimum setpoints

You cannot configure the curve with temperatures that are higher or lower than the set maximum and minimum setpoints for that zone or for the tank. When the maximum or minimum setpoint is reached, the curve flattens out.

To fine-tune the weather-dependent curve: slope-offset curve

The following table describes how to fine-tune the weather-dependent curve of a zone or tank:

You feel ...		Fine-tune with slope and offset:	
At regular outdoor temperatures ...	At cold outdoor temperatures ...	Slope	Offset
OK	Cold	↑	—

You feel ...		Fine-tune with slope and offset:	
At regular outdoor temperatures ...	At cold outdoor temperatures ...	Slope	Offset
OK	Hot	↓	—
Cold	OK	↓	↑
Cold	Cold	—	↑
Cold	Hot	↓	↑
Hot	OK	↑	↓
Hot	Cold	↑	↓
Hot	Hot	—	↓

To fine-tune the weather-dependent curve: 2-points curve

The following table describes how to fine-tune the weather-dependent curve of a zone or tank:

You feel ...		Fine-tune with setpoints:			
At regular outdoor temperatures ...	At cold outdoor temperatures ...	Y2 ^(a)	Y1 ^(a)	X1 ^(a)	X2 ^(a)
OK	Cold	↑	—	↑	—
OK	Hot	↓	—	↓	—
Cold	OK	—	↑	—	↑
Cold	Cold	↑	↑	↑	↑
Cold	Hot	↓	↑	↓	↑
Hot	OK	—	↓	—	↓
Hot	Cold	↑	↓	↑	↓
Hot	Hot	↓	↓	↓	↓

^(a) See "7.3.2 2-points curve" [p 33].

7.4 Settings menu

You can set additional settings using the main menu screen and its submenus. The most important settings are presented here.

7.4.1 Main zone

Thermostat type

Only applicable in external room thermostat control.



NOTICE

If an external room thermostat is used, the external room thermostat will control the room frost protection. However, the room frost protection is only possible if [C.2] Space heating/cooling=0n.

#	Code	Description
[2.A]	[C-05]	External room thermostat type for the main zone: <ul style="list-style-type: none"> • 1: 1 contact: The used external room thermostat can only send a thermo ON/OFF condition. There is no separation between heating or cooling demand. • 2: 2 contacts: The used external room thermostat can send a separate heating/cooling thermo ON/OFF condition.

7.4.2 Additional zone

Thermostat type

Only applicable in external room thermostat control. For more info about the functionality, see "7.4.1 Main zone" [p 34].

#	Code	Description
[3.A]	[C-06]	External room thermostat type for the additional zone: <ul style="list-style-type: none"> ▪ 1: 1 contact ▪ 2: 2 contacts

7.4.3 Information

Dealer information

The installer can fill in his contact number here.

#	Code	Description
[8.3]	N/A	Number that users can call in case of problems.

7 Configuration

7.5 Menu structure: Overview installer settings

[9] Installer settings	[9.2] Domestic hot water
Configuration wizard	Domestic hot water
Domestic hot water	DHW pump
Backup heater	DHW pump schedule
Emergency	Solar
Balancing	[9.3] Backup heater
Water pipe freeze prevention	Backup heater type
Benefit kWh power supply	Voltage
Power consumption control	Configuration
Energy metering	Capacity step 1
Sensors	Additional capacity step 2
Bivalent	Equilibrium
Alarm output	Equilibrium temperature
Auto restart	Operation
Power saving function	[9.5] Emergency
Disable protections	Emergency
Forced defrost	Compressor forced off
Overview field settings	[9.6] Balancing
Export MMI settings	Space heating priority
Bizone kit	Priority temperature
	Offset BSH setpoint
	Anti-recycle timer
	Minimum running timer
	Maximum running timer
	Additional timer
	[9.8] Benefit kWh power supply
	Allow heater
	Allow pump
	Benefit kWh power supply
	Smart grid operation mode
	Allow electrical heaters
	Enable room buffering
	Limit setting kW
	[9.9] Power consumption control
	Power consumption control
	Type
	Limit
	Limit 1
	Limit 2
	Limit 3
	Limit 4
	Priority heater
	(*) BBR16 activation
	(*) BBR16 power limit
	[9.A] Energy metering
	Electricity meter 1
	Electricity meter 2
	[9.B] Sensors
	External sensor
	Ext. amb. sensor offset
	Averaging time
	[9.C] Bivalent
	Bivalent
	Boiler efficiency
	Temperature
	Hysteresis
	[9.P] Bizone kit
	Bizone kit installed
	Bizone system type
	Add zone pump fixed PWM
	Main zone pump fixed PWM
	Mixing valve turning time

(*) Only applicable in Swedish language.



INFORMATION

Solar kit settings are shown but are NOT applicable for this unit. Settings shall NOT be used or changed.



INFORMATION

Depending on the selected installer settings and unit type, settings will be visible/invisible.

8 Commissioning



NOTICE

General commissioning checklist. Next to the commissioning instructions in this chapter, a general commissioning checklist is also available on the Daikin Business Portal (authentication required).

The general commissioning checklist is complementary to the instructions in this chapter and can be used as a guideline and reporting template during the commissioning and hand-over to the user.




NOTICE

ALWAYS operate the unit with thermistors and/or pressure sensors/switches. If NOT, burning of the compressor might be the result.



NOTICE



Make sure both air purge valves (one on the magnetic filter and one on the backup heater) are open.

All automatic air purge valves MUST remain open after commissioning.



NOTICE

Pump. To prevent blocking of the pump rotor, commission the unit as quickly as possible after filling the water circuit.



INFORMATION

Protective functions – "Installer-on-site mode". The software is equipped with protective functions, such as room antifrost. The unit automatically runs these functions when necessary.

During installation or service this behaviour is undesired. Therefore, the protective functions can be disabled:

- **At first power-on:** The protective functions are disabled by default. After 12 hours they will be automatically enabled.
- **Afterwards:** An installer can manually disable the protective functions by setting [9.G]: Disable protections=Yes. After his work is done, he can enable the protective functions by setting [9.G]: Disable protections=No.

Also see "[Protective functions](#)" [p. 29].

8.1 Checklist before commissioning

After the installation of the unit, first check the items listed below. Once all checks are fulfilled, the unit MUST be closed. Power-up the unit after it is closed.

<input type="checkbox"/>	You read the complete installation instructions, as described in the installer reference guide .
<input type="checkbox"/>	The indoor unit is properly mounted.
<input type="checkbox"/>	The outdoor unit is properly mounted.

<input type="checkbox"/>	The following field wiring has been carried out according to this document and the applicable legislation: <ul style="list-style-type: none"> ▪ Between the local supply panel and the outdoor unit ▪ Between indoor unit and outdoor unit ▪ Between the local supply panel and the indoor unit ▪ Between the indoor unit and the valves (if applicable) ▪ Between the indoor unit and the room thermostat (if applicable)
<input type="checkbox"/>	The system is properly earthed and the earth terminals are tightened.
<input type="checkbox"/>	The fuses or locally installed protection devices are installed according to this document, and have NOT been bypassed.
<input type="checkbox"/>	The power supply voltage matches the voltage on the identification label of the unit.
<input type="checkbox"/>	There are NO loose connections or damaged electrical components in the switch box.
<input type="checkbox"/>	There are NO damaged components or squeezed pipes on the inside of the indoor and outdoor units.
<input type="checkbox"/>	Backup heater circuit breaker F1B (field supply) is turned ON.
<input type="checkbox"/>	There are NO refrigerant leaks .
<input type="checkbox"/>	The refrigerant pipes (gas and liquid) are thermally insulated.
<input type="checkbox"/>	The correct pipe size is installed and the pipes are properly insulated.
<input type="checkbox"/>	There is NO water leak inside the indoor unit.
<input type="checkbox"/>	The shut-off valves are properly installed and fully open.
<input type="checkbox"/>	The stop valves (gas and liquid) on the outdoor unit are fully open.
<input type="checkbox"/>	The air purge valve is open (at least 2 turns).
<input type="checkbox"/>	The pressure relief valve purges water when opened. Clean water MUST come out.
<input type="checkbox"/>	The minimum water volume is guaranteed in all conditions. See "To check the water volume and flow rate" in " 5.3 Preparing water piping " [p. 16].
<input type="checkbox"/>	The domestic hot water tank is filled completely.

8.2 Checklist during commissioning

<input type="checkbox"/>	The minimum flow rate during backup heater/defrost operation is guaranteed in all conditions. See "To check the water volume and flow rate" in " 5.3 Preparing water piping " [p. 16].
<input type="checkbox"/>	To perform an air purge .
<input type="checkbox"/>	To perform a test run .
<input type="checkbox"/>	To perform an actuator test run .
<input type="checkbox"/>	Underfloor screed dryout function The underfloor screed dryout function is started (if necessary).

8 Commissioning

8.2.1 To check the minimum flow rate

1	Check the hydraulic configuration to find out which space heating loops can be closed by mechanical, electronic, or other valves.	—
2	Close all space heating loops that can be closed.	—
3	Start the pump test run (see "8.2.4 To perform an actuator test run" ▶ 38).	—
4	Read out the flow rate ^(a) and modify the bypass valve setting to reach the minimum required flow rate + 2 l/min.	—

^(a) During pump test run, the unit can operate below the minimum required flow rate.

If operation is...	Then the minimum required flow rate is...
Cooling	16 l/min
Heating/defrost	22 l/min
Domestic hot water production	

8.2.2 To perform an air purge

Conditions: Make sure all operation is disabled. Go to [C]: Operation and turn off Space heating/cooling and Tank operation.

1	Set the user permission level to Installer. See "To change the user permission level" ▶ 28].	—
2	Go to [A.3]: Commissioning > Air purge.	🔧⏸️
3	Select OK to confirm. Result: The air purge starts. It stops automatically when air purge cycle is finished. To stop the air purge manually:	🔧⏸️
1	Go to Stop air purge.	🔧⏸️
2	Select OK to confirm.	🔧⏸️

Air purging heat emitters or collectors

We recommend to purge air with the unit's air purge function (see above). However, if you purge air from the heat emitters or collectors, mind the following:



WARNING

Air purging heat emitters or collectors. Before you purge air from heat emitters or collectors, check if or is displayed on the home screen of the user interface.

- If not, you can purge air immediately.
- If yes, make sure that the room where you want to purge air is sufficiently ventilated. **Reason:** Refrigerant might leak into the water circuit, and subsequently into the room when you purge air from the heat emitters or collectors.

8.2.3 To perform an operation test run

Conditions: Make sure all operation is disabled. Go to [C]: Operation and turn off Space heating/cooling and Tank operation.

1	Set the user permission level to Installer. See "To change the user permission level" ▶ 28].	—
2	Go to [A.1]: Commissioning > Operation test run.	🔧⏸️
3	Select a test from the list. Example: Heating.	🔧⏸️

4	Select OK to confirm. Result: The test run starts. It stops automatically when ready (±30 min).	🔧⏸️
	To stop the test run manually:	—
1	In the menu, go to Stop test run.	🔧⏸️
2	Select OK to confirm.	🔧⏸️



INFORMATION

If the outdoor temperature is outside the range of operation, the unit may NOT operate or may NOT deliver the required capacity.

To monitor leaving water and tank temperatures

During test run, the correct operation of the unit can be checked by monitoring its leaving water temperature (heating/cooling mode) and tank temperature (domestic hot water mode).

To monitor the temperatures:

1	In the menu, go to Sensors.	🔧⏸️
2	Select the temperature information.	🔧⏸️

8.2.4 To perform an actuator test run

Conditions: Make sure all operation is disabled. Go to [C]: Operation and turn off Space heating/cooling and Tank operation.

Purpose

Perform an actuator test run to confirm the operation of the different actuators. For example, when you select Pump, a test run of the pump will start.

1	Set the user permission level to Installer. See "To change the user permission level" ▶ 28].	—
2	Go to [A.2]: Commissioning > Actuator test run.	🔧⏸️
3	Select a test from the list. Example: Pump.	🔧⏸️
4	Select OK to confirm. Result: The actuator test run starts. It stops automatically when ready (±30 min). To stop the test run manually:	🔧⏸️
1	In the menu, go to Stop test run.	🔧⏸️
2	Select OK to confirm.	🔧⏸️

Possible actuator test runs

- Backup heater 1 test
- Backup heater 2 test
- Pump test



INFORMATION






Make sure that all air is purged before executing the test run. Also avoid disturbances in the water circuit during the test run.

- Shut off valve test
- Diverter valve test (3-way valve for switching between space heating and tank heating)
- Bivalent signal test
- Alarm output test
- C/H signal test
- DHW pump test
- Bizone kit direct pump test (bizone kit EKMIKPOA or EKMIKPHA)
- Bizone kit mixed pump test (bizone kit EKMIKPOA or EKMIKPHA)

- Bizone kit mixing valve test (bizone kit EKMIKPOA or EKMIKPHA)

8.2.5 To perform an underfloor heating screed dryout

Conditions: Make sure all operation is disabled. Go to [C]: Operation and turn off Space heating/cooling and Tank operation.

1	Set the user permission level to Installer. See "To change the user permission level" [p 28].	—
2	Go to [A.4]: Commissioning > UFH screed dryout.	
3	Set a dryout program: go to Program and use the UFH screed dryout programming screen.	
4	Select OK to confirm. Result: The underfloor heating screed dryout starts. It stops automatically when done. To stop the test run manually:	
1	Go to Stop UFH screed dryout.	
2	Select OK to confirm.	



NOTICE

To perform an underfloor heating screed dryout, room frost protection needs to be disabled ([2-06]=0). By default, it is enabled ([2-06]=1). However, due to the "installer-on-site" mode (see "Commissioning"), room frost protection will be automatically disabled for 12 hours after the first power-on.

If the screed dryout still needs to be performed after the first 12 hours of power-on, manually disable room frost protection by setting [2-06] to "0", and KEEP it disabled until the screed dryout has finished. Ignoring this notice will result in cracking of the screed.



NOTICE

For the underfloor heating screed dryout to be able to start, make sure the following settings are met:

- [4-00]=1
- [C-02]=0
- [D-01]=0
- [4-08]=0
- [4-01]≠1

9 Hand-over to the user


Once the test run is finished and the unit operates properly, please make sure the following is clear for the user:

- Fill in the installer setting table (in the operation manual) with the actual settings.
- Make sure that the user has the printed documentation and ask him/her to keep it for future reference. Inform the user that he can find the complete documentation at the URL mentioned earlier in this manual.
- Explain the user how to properly operate the system and what to do in case of problems.
- Show the user what to do for the maintenance of the unit.
- Explain the user about energy saving tips as described in the operation manual.

10 Technical data

A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible). The **full set** of latest technical data is available on the Daikin Business Portal (authentication required).

10.1 Piping diagram: Indoor unit



- A** Water side
- B** Refrigerant side
- C** Field installed (delivered with the unit)
- a1** Space heating/cooling – Water IN (screw connection, 1")
- a2** Space heating/cooling – Water OUT (screw connection, 1")
- b1** DHW – Cold water IN (screw connection, 3/4")
- b2** DHW – Hot water OUT (screw connection, 3/4")
- c** Recirculation connection
- d1** Gas refrigerant IN (heating mode; condenser)
- d2** Liquid refrigerant OUT (heating mode; condenser)
- e1** Liquid refrigerant IN (cooling mode; evaporator)
- e2** Gas refrigerant OUT (cooling mode; evaporator)
- f** Plate heat exchanger
- g** Shut-off valve for service
- h** Flexible pipe
- i** Expansion vessel
- j** Magnetic filter/dirt separator
- k** Safety valve
- l** Automatic air purge
- m** Drain valve
- n** Pump
- o** Backup heater

- B2L** Flow sensor
- B1PW** Space heating water pressure sensor
- M3S** 3-way valve (space heating/domestic hot water)

- Thermistors:**
- R1T** Outlet water heat exchanger
 - R2T** Outlet water backup heater
 - R3T** Refrigerant liquid side
 - R4T** Inlet water
 - R5T, R8T** Tank

- Connections:**
- Screw connection
 - Flare connection
 - Quick coupling
 - Brazed connection

10.2 Wiring diagram: Indoor unit

See the internal wiring diagram supplied with the unit (on the inside of the indoor unit switch box cover). The abbreviations used are listed below.

Notes to go through before starting the unit

English	Translation
Notes to go through before starting the unit	Notes to go through before starting the unit
X1M	Main terminal
X2M	Field wiring terminal for AC
X5M	Field wiring terminal for DC
X6M	Backup heater power supply terminal
X10M	Smart Grid terminal
-----	Earth wiring
-----	Field supply
①	Several wiring possibilities
	Option
	Not mounted in switch box
	Wiring depending on model
	PCB
Note 1: Connection point of the power supply for the BUH should be foreseen outside the unit.	Note 1: Connection point of the power supply for the backup heater heater should be foreseen outside the unit.
Backup heater power supply	Backup heater power supply
<input type="checkbox"/> 6T1 (3~, 230 V, 6 kW)	<input type="checkbox"/> 6T1 (3~, 230 V, 6 kW)
<input type="checkbox"/> 6V3 (1N~, 230 V, 6 kW)	<input type="checkbox"/> 6V3 (1N~, 230 V, 6 kW)
<input type="checkbox"/> 6WN/9WN (3N~, 400 V, 6/9 kW)	<input type="checkbox"/> 6WN/9WN (3N~, 400 V, 6/9 kW)
User installed options	User installed options
<input type="checkbox"/> Remote user interface	<input type="checkbox"/> Dedicated Human Comfort Interface (BRC1HHDA used as room thermostat)
<input type="checkbox"/> Ext. indoor thermistor	<input type="checkbox"/> External indoor thermistor
<input type="checkbox"/> Ext outdoor thermistor	<input type="checkbox"/> External outdoor thermistor
<input type="checkbox"/> Digital I/O PCB	<input type="checkbox"/> Digital I/O PCB
<input type="checkbox"/> Demand PCB	<input type="checkbox"/> Demand PCB
<input type="checkbox"/> Safety thermostat	<input type="checkbox"/> Safety thermostat
<input type="checkbox"/> Smart Grid	<input type="checkbox"/> Smart Grid
<input type="checkbox"/> WLAN module	<input type="checkbox"/> WLAN module
<input type="checkbox"/> WLAN cartridge	<input type="checkbox"/> WLAN cartridge
<input type="checkbox"/> Bizone mixing kit	<input type="checkbox"/> Bizone mixing kit
Main LWT	Main leaving water temperature
<input type="checkbox"/> On/OFF thermostat (wired)	<input type="checkbox"/> ON/OFF thermostat (wired)
<input type="checkbox"/> On/OFF thermostat (wireless)	<input type="checkbox"/> ON/OFF thermostat (wireless)
<input type="checkbox"/> Ext. thermistor	<input type="checkbox"/> External thermistor
<input type="checkbox"/> Heat pump convector	<input type="checkbox"/> Heat pump convector
Add LWT	Additional leaving water temperature
<input type="checkbox"/> On/OFF thermostat (wired)	<input type="checkbox"/> ON/OFF thermostat (wired)
<input type="checkbox"/> On/OFF thermostat (wireless)	<input type="checkbox"/> ON/OFF thermostat (wireless)
<input type="checkbox"/> Ext. thermistor	<input type="checkbox"/> External thermistor
<input type="checkbox"/> Heat pump convector	<input type="checkbox"/> Heat pump convector

Position in switch box

English	Translation
Position in switch box	Position in switch box

Legend

A1P	Main PCB
A2P	* ON/OFF thermostat (PC=power circuit)
A3P	* Heat pump convector
A4P	* Digital I/O PCB
A8P	* Demand PCB
A11P	Main PCB of the MMI (= user interface of the indoor unit)
A14P	* PCB of the dedicated Human Comfort Interface (BRC1HHDA used as room thermostat)
A15P	* Receiver PCB (wireless ON/OFF thermostat)
A20P	* WLAN module
A30P	* Bizone mixing kit PCB
CN* (A4P)	* Connector
DS1(A8P)	* DIP switch
F1B	# Overcurrent fuse backup heater
F1U, F2U (A4P)	* Fuse 5 A 250 V for digital I/O PCB
K1A, K2A	* High voltage Smart Grid relay
K1M, K2M	Contactors backup heater
K5M	Safety contactors backup heater
K*R (A4P)	Relay on PCB
M2P	# Domestic hot water pump
M2S	# 2-way valve for cooling mode
PC (A15P)	* Power circuit
PHC1 (A4P)	* Optocoupler input circuit
Q1L	Thermal protector backup heater
Q4L	# Safety thermostat
Q*DI	# Earth leakage circuit breaker
R1H (A2P)	* Humidity sensor
R1T (A2P)	* Ambient sensor ON/OFF thermostat
R2T (A2P)	* External sensor (floor or ambient)
R6T	* External indoor or outdoor ambient thermistor
S1S	# Preferential kWh rate power supply contact
S2S	# Electrical meter pulse input 1
S3S	# Electrical meter pulse input 2
S4S	# Smart Grid feed-in
S6S~S9S	* Digital power limitation inputs
S10S-S11S	# Low voltage Smart Grid contact
SS1 (A4P)	* Selector switch
TR1	Power supply transformer
X6M	# Backup heater power supply terminal strip
X10M	* Smart Grid power supply terminal strip
X*, X*A, X*Y*, Y*	Connector
X*M	Terminal strip

* Optional

Field supply

Translation of text on wiring diagram

English	Translation
(1) Main power connection	(1) Main power connection


10 Technical data

English	Translation
For HP tariff	For heat pump tariff
Indoor unit supplied from outdoor	Indoor unit supplied from outdoor
Normal kWh rate power supply	Normal kWh rate power supply
Only for normal power supply (standard)	Only for normal power supply (standard)
Only for preferential kWh rate power supply (outdoor)	Only for preferential kWh rate power supply (outdoor)
Outdoor unit	Outdoor unit
Preferential kWh rate power supply contact: 16 V DC detection (voltage supplied by PCB)	Preferential kWh rate power supply contact: 16 V DC detection (voltage supplied by PCB)
SWB	Switch box
Use normal kWh rate power supply for indoor unit	Use normal kWh rate power supply for indoor unit
(2) Backup heater power supply	(2) Backup heater power supply
Only for ***	Only for ***
(3) User interface	(3) User interface
Only for remote user interface	Only for the dedicated Human Comfort Interface (BRC1HHDA used as room thermostat)
SD card	Card slot for WLAN cartridge
SWB	Switch box
WLAN cartridge	WLAN cartridge
(5) Ext. thermistor	(5) External thermistor
SWB	Switch box
(6) Field supplied options	(6) Field supplied options
12 V DC pulse detection (voltage supplied by PCB)	12 V DC pulse detection (voltage supplied by PCB)
230 V AC Control Device	230 V AC Control Device
230 V AC supplied by PCB	230 V AC supplied by PCB
Bizone mixing kit	Bizone mixing kit
Continuous	Continuous current
DHW pump output	Domestic hot water pump output
DHW pump	Domestic hot water pump
Electrical meters	Electrical meters
For HV smartgrid	For high voltage Smart Grid
For LV smartgrid	For low voltage Smart Grid
For safety thermostat	For safety thermostat
For smartgrid	For Smart Grid
Inrush	Inrush current
Max. load	Maximum load
Normally closed	Normally closed
Normally open	Normally open
Safety thermostat contact: 16 V DC detection (voltage supplied by PCB)	Safety thermostat contact: 16 V DC detection (voltage supplied by PCB)
Shut-off valve	Shut-off valve
Smartgrid contacts	Smart Grid contacts
Smartgrid PV power pulse meter	Smart Grid photovoltaic power pulse meter
SWB	Switch box
(7) Option PCBs	(7) Option PCBs
Alarm output	Alarm output
Changeover to ext. heat source	Changeover to external heat source
Max. load	Maximum load

English	Translation
Min. load	Minimum load
Only for demand PCB option	Only for demand PCB option
Only for digital I/O PCB option	Only for digital I/O PCB option
Options: ext. heat source output, alarm output	Options: external heat source output, alarm output
Options: On/OFF output	Options: ON/OFF output
Power limitation digital inputs: 12 V DC / 12 mA detection (voltage supplied by PCB)	Power limitation digital inputs: 12 V DC / 12 mA detection (voltage supplied by PCB)
Space C/H On/OFF output	Space cooling/heating ON/OFF output
SWB	Switch box
(8) External On/OFF thermostats and heat pump convector	(8) External ON/OFF thermostats and heat pump convector
Additional LWT zone	Additional leaving water temperature zone
Main LWT zone	Main leaving water temperature zone
Only for external sensor (floor/ambient)	Only for external sensor (floor or ambient)
Only for heat pump convector	Only for heat pump convector
Only for wired On/OFF thermostat	Only for wired ON/OFF thermostat
Only for wireless On/OFF thermostat	Only for wireless ON/OFF thermostat

Electrical connection diagram

For more details, please check the unit wiring.



4D128798

ERC



4P643599-1 B 00000007

Copyright 2021 Daikin

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

4P643599-1B 2021.10