




Installation and operation manual

Split system air conditioners



FCAHG71HVEB
FCAHG100HVEB
FCAHG125HVEB
FCAHG140HVEB

Installation and operation manual
Split system air conditioners

English

CE - DECLARATION-OF-CONFORMITY
CE - KONFORMITÄTSERKLÄRUNG
CE - DECLARATION-OF-CONFORMITE
CE - KONFORMITETSERKLÄRING
CE - DECLARACION-DE-CONFORMIDAD
CE - DICHIARAZIONE-DI-CONFORMITÀ
CE - ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ

DECLARAÇÃO-DE-CONFORMIDADE
ЗАРЯТЕНЕ-О-ООТБЕТАВИ
OVERENSSTEMELSEKLÆRING
FÖRSÄKRAN-OM-ÖVERENSTÄMME

CE - ERKLÆRING OM-SAMSVAR
CE - ILMOITUS-YHDENMUKAISUUDESTA
CE - PROHLÁŠENÍ-O-SHOĐĚ

CE - IZJAVA O USKLADENOSTI
CE - MEGFELELŐSÉGI NYILATKOZAT
CE - DEKLARACIJA ZGODNOSTI
CE - DECLARATION DE CONFORMITE

CE - IZJAVA O SKLADNOSTI
CE - VASTAVUSDEKLARATSIOON
CE - ДЕКЛАРАЦИЯ-ЗА СЪОТВЕТСТВИЕ

CE - ATITIKTIES-DEKLARĀCIJA
CE - ATBILSTĪBAS-DEKLARĀCIJA
CE - VYHLÁŠENIE-ZHODY
CE - UYGUNLŪK-BEYANI

Daikin Industries Czech Republic s.r.o.

[illegible]

09 10 11 12 13 14 15 16

Уже в начале 1990-х годов, когда в СССР активно развивалась компьютерная техника, специалисты по климату начали использовать компьютерные модели для исследования климата. В то время компьютерные модели были очень простыми и не учитывали многие физические процессы, но они позволили получить первые количественные оценки изменений климата. В 1990-е годы появились более сложные модели, которые учитывали больше физических процессов, таких как перенос тепла, влаги и импульса, а также химические и биологические процессы. Эти модели стали использоваться для оценки воздействия различных сценариев развития человечества на климат. В 2000-е годы появились еще более сложные модели, которые учитывали еще больше физических процессов, таких как взаимодействие климата с биосферой и геосферой. Эти модели стали использоваться для оценки воздействия различных сценариев развития человечества на климат. В настоящее время компьютерные модели являются основным инструментом для исследования климата. Они позволяют получать количественные оценки изменений климата и оценивать воздействие различных сценариев развития человечества на климат.

тение:

deklaruje na własną wyłączną odpowiedzialność, że nie posiada wiedzy, która mogłaby wskazywać na to, iż dane informacje nie są prawdziwe. Wskazuje, że nie posiada wiedzy, która mogłaby wskazywać na to, iż dane informacje nie są prawdziwe. Wskazuje, że nie posiada wiedzy, która mogłaby wskazywać na to, iż dane informacje nie są prawdziwe.

aktorów, których dotyczy niniejsza deklaracja:
se refera această declarație:
se izjava nanaša:
vad klimaseadmerte mudelid:
ция, за която се отнася тази декларация;
kulturi, yu taikoma ši deklaracija:
tätlig, uz kurem attiecas ši deklaracija:
tore sa vziahuje toto vhlásenie:

FCAHG71HVEB, FCAHG100HVEB, FCAHG125HVEB, FCAHG140HVEB,

[illegible]

05 están en conformidad con la(s) siguiente(s) norma(s) u otros) documento(s) normativo(s), siempre que sean utilizados de acuerdo con nuestras
instituciones:
06 son conformes al(l) siguiente(s) standard(s) o al(los) documento(s) a carácter normativo, a partir del venidero uso en conformidad ale nostre sinuzuraz
07 esta conjungida me tal el docubolod el troyobid el dolo bryod el kowowid, urto my tyobobed el xepoyunbyvra

σύνταγμα με τις οδηγίες μας.

EN60335-2-40,

01	following the provisions of:	01	nakolju predpisov:
02	gemäß den Vorschriften der:	02	konkretno na situacijah des:
03	conformément aux dispositions de:	03	ovetnostnosti za beglajenje vani:
04	conformemente alle disposizioni de:	04	squendo las disposiciones de:
05	conformément aux dispositions de:	05	sejundo las disposiciones per:
06	conformément aux dispositions de:	06	terjunoj na borbom tvoj:
07	conformément aux dispositions de:	07	acordo com o previso et:
08	conformément aux dispositions de:	08	в соответствии с положениями:
09	conformément aux dispositions de:	09	в соответствии с положениями:
10	conformément aux dispositions de:	10	in urma prevederilor:
11	conformément aux dispositions de:	11	in urma prevederilor:
12	conformément aux dispositions de:	12	in urma prevederilor:
13	conformément aux dispositions de:	13	in urma prevederilor:
14	conformément aux dispositions de:	14	in urma prevederilor:
15	conformément aux dispositions de:	15	in urma prevederilor:
16	conformément aux dispositions de:	16	in urma prevederilor:
17	conformément aux dispositions de:	17	in urma prevederilor:
18	conformément aux dispositions de:	18	in urma prevederilor:
19	conformément aux dispositions de:	19	in urma prevederilor:
20	conformément aux dispositions de:	20	in urma prevederilor:

01 Note	as set out in <A> and judged positively by according to the Certificate <C>	06 Note
02 Hinweis	was in <A> aufgeführt und von positiv beurteilt gemäß Zertifikat <C>	07 Zhiukovskij
03 Remarque	tel que défini dans <A> et évalué positivement par 08 Note	
04 Bemerk	zodas vėrėtinai išsakyta teigiamai pagal pažymėjimą <C>	09 Письма в нас
05 Nota	como se establece en <A> y es valorado positivamente por de acuerdo con el Certificado <C>	10 Bemerk

01** DICZ*** is authorised to compile the Technica Construction File.
02** DICZ*** hat die Berechtigung die Technische Konstruktionsakte zusammenzustellen.
03** DICZ*** est autorisé à compiler le Dossier de Construction Technique.
04** DICZ*** is bevoegd om het Technisch Constructiedossier samen te stellen.
05** DICZ*** está autorizado a compilar el Archivo de Construcción Técnica.
06** DICZ*** è autorizzata a redurre il File Tecnico di Costruzione.

***DICz = Daikin Industries Czech Republic s.r.o.



[Signature]

Yasuto Hiraoka
Managing Director
Pilsen, 1st of February

Pilsen, 1st of February 2019

DAIKIN INDUSTRIES CZECH REPUBLIC s.r.o.

U Nové Hospody 1/1155, 301 00 Plzeň Skvrňany,

Czech Republic

[illegible][illegible]

19^o DIC^{***} je poboljšanje za sastav datoteke s tehnično mapo.
 20^o DIC^{***} on volitku koštama tehniški dokumentaciji.
 21^o DIC^{***} je otvorena za sastav Arta za tehničku konstrukciju.
 22^o DIC^{***} yra garbia sudaryti s tehniškos konstrukcijos laia.
 23^o DIC^{***} je autorizats sąrašyti techniško dokumentaciją.
 24^o DIC^{***} je pravršena vyvoti sūbor techniškej konstrukcije.
 25^o DIC^{***} Teknik Yaol Dosymları derleme veektir.

***DICz = Daikin Industries Czech Republic s.r.o.

Table of Contents

1 About the documentation	3
1.1 About this document.....	3
For the installer	4
2 About the box	4
2.1 Indoor unit	4
2.1.1 To remove the accessories from the indoor unit.....	4
3 Preparation	4
3.1 Preparing the installation site	4
3.1.1 Installation site requirements of the indoor unit	4
4 Installation	5
4.1 Mounting the indoor unit.....	5
4.1.1 Guidelines when installing the indoor unit.....	5
4.1.2 Guidelines when installing the drain piping.....	6
4.2 Connecting the refrigerant piping	7
4.2.1 To connect the refrigerant piping to the indoor unit	7
4.3 Connecting the electrical wiring.....	8
4.3.1 Specifications of standard wiring components.....	8
4.3.2 To connect the electrical wiring to the indoor unit.....	8
5 Configuration	9
5.1 Field setting	9
6 Commissioning	10
6.1 Checklist before commissioning	10
6.2 To perform a test run	10
6.3 Error codes when performing a test run	11
7 Disposal	11
8 Technical data	11
8.1 Piping diagram: Indoor unit	12
8.2 Wiring diagram	12
8.2.1 Unified wiring diagram legend.....	12
For the user	13
9 About the system	13
10 User interface	13
11 Before operation	13
12 Operation	13
12.1 Operation range	13
12.2 Operating the system	14
12.2.1 About operating the system	14
12.2.2 About cooling, heating, fan only, and automatic operation	14
12.2.3 About the heating operation.....	14
12.2.4 To operate the system	14
12.3 Using the dry program.....	14
12.3.1 About the dry program	14
12.3.2 To use the dry program.....	14
12.4 Adjusting the air flow direction.....	14

12.4.1 About the air flow flap	14
12.5 Active circulation airflow	14
12.5.1 To start the active circulation airflow	14
13 Maintenance and service	15
13.1 Precautions for maintenance and service	15
13.2 Cleaning the air filter, suction grille, air outlet and outside panels	15
13.2.1 To clean the air filter	15
13.2.2 To clean the suction grille	16
13.2.3 To clean the air outlet and outside panels	16
13.3 Maintenance after a long stop period	17
13.4 Maintenance before a long stop period	17
13.5 About the refrigerant.....	17
14 Troubleshooting	17
15 Disposal	17

1 About the documentation

1.1 About this document

Target audience

Authorised installers + end users



INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry, and on farms, or for commercial and household use by lay persons.

Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
 - Safety instructions that you must read before installing
 - Format: Paper (in the box of the indoor unit)
- **Indoor unit installation and operation manual:**
 - Installation and operation instructions
 - Format: Paper (in the box of the indoor unit)
- **Installer and user reference guide:**
 - Preparation of the installation, good practices, reference data,...
 - Detailed step-by-step instructions and background information for basic and advanced usage
 - Format: Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

The original documentation is written in English. All other languages are translations.

Technical engineering data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin Business Portal (authentication required).

2 About the box

For the installer

2 About the box


2.1 Indoor unit



WARNING: MILDLY FLAMMABLE MATERIAL

The R32 refrigerant (if applicable) in this unit is mildly flammable. Refer to the outdoor unit specifications for the type of refrigerant to be used.

2.1.1 To remove the accessories from the indoor unit



- a Paper pattern for installation (upper part of packing)
- b General safety precautions
- c Indoor unit installation and operation manual
- d Installation guide
- e Washers for hanger brackets
- f Screws (to temporarily attach the paper pattern for installation to the indoor unit)
- g Cable ties
- h Metal clamp
- i Sealing pads: Large (drain pipe), medium 1 (gas pipe), medium 2 (liquid pipe), small (electrical wiring)
- j Drain hose
- k Insulation piece: Small (liquid pipe)
- l Insulation piece: Large (gas pipe)
- m Insulation piece (drain pipe)

3 Preparation

3.1 Preparing the installation site



WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).

3.1.1 Installation site requirements of the indoor unit



INFORMATION

The sound pressure level is less than 70 dBA.




CAUTION

Appliance NOT accessible to the general public, install it in a secured area, protected from easy access.


This unit, both indoor and outdoor, is suitable for installation in a commercial and light industrial environment.

- **Spacing.** Mind the following requirements:



- A Minimum distance to the wall (see below)
- B Minimum and maximum distance to the floor (see below)
- C ≥311 mm: In case of installation with standard panel
≥353 mm: In case of installation with design panel
≥391 mm: In case of installation with self-cleaning panel
≥361 mm: In case of installation with standard panel + fresh air intake kit
≥403 mm: In case of installation with design panel + fresh air intake kit
- a Indoor unit
- b Lighting (the figure shows ceiling-mounted lighting, but recessed lighting is also allowed)
- c Air fan
- d Static volume (example: table)

- **A: Minimum distance to the wall.** Depends on the airflow directions towards the wall.



- **B: Minimum and maximum distance to the floor:**
 - Minimum: 2.7 m to avoid accidental touching.
 - Maximum: Depends on the airflow directions and the capacity class. See "5.1 Field setting" [p 9].



INFORMATION

Maximum distance to the floor for the 3-way and the 4-way airflow (which require an optional blocking pad kit) may differ. See the installation manual of the optional blocking pad kit.

4 Installation

4.1 Mounting the indoor unit

4.1.1 Guidelines when installing the indoor unit



INFORMATION

Optional equipment. When installing optional equipment, also read the installation manual of the optional equipment. Depending on the field conditions, it might be easier to install the optional equipment first.


- **In case of installation with a fresh air intake kit.** Install the fresh air intake kit always **before** installing the unit.
- **Decoration panel.** Install the decoration panel always **after** installing the unit.



NOTICE


After installing the decoration panel:

- Make sure there is no gap between the unit body and the decoration panel. **Possible consequence:** Air might leak and cause dew drop.
 - Make sure no oil remains on the plastic parts of the decoration panel. **Possible consequence:** Degradation and damage of plastic parts.
- **Ceiling strength.** Check whether the ceiling is strong enough to support the weight of the unit. If there is a risk, reinforce the ceiling before installing the unit.
 - For existing ceilings, use anchors.
 - For new ceilings, use sunken inserts, sunken anchors or other field supplied parts.




- A** 50~100 mm: In case of installation with standard panel
 100~150 mm: In case of installation with fresh air intake kit or design panel
 130~180 mm: In case of installation with self-cleaning decoration panel
- a Ceiling slab
 b Anchor
 c Long nut or turnbuckle
 d Suspension bolt
 e Suspended ceiling

- **Suspension bolts.** Use M8~M10 suspension bolts for installation. Attach the hanger bracket to the suspension bolt. Fix it securely using a nut and washer from the upper and lower sides of the hanger bracket.



- a1 Nut (field supply)
 a2 Double nut (field supply)
 b Washer (accessories)
 c Hanger bracket (attached to the unit)

- **Paper pattern for installation** (upper part of the packing). Use the paper pattern to determine the correct horizontal positioning. It contains the necessary dimensions and centers. You can attach the paper pattern to the unit.



- a Centre of the unit
 b Centre of the ceiling opening
 c Paper pattern for installation (upper part of the packing)
 d Screws (accessories)


Ceiling opening and unit:

- Make sure the ceiling opening is within the following limits:

Minimum: 860 mm to be able to fit the unit.

Maximum: 910 mm to ensure enough overlap between the decoration panel and the suspended ceiling. If the ceiling opening is larger, add extra ceiling material.

- Make sure the unit and its hanger brackets (suspension) are centered within the ceiling opening.




- a Drain piping
 b Refrigerant piping
 c Hanger bracket pitch (suspension)
 d Unit
 e Ceiling opening
 f Decoration panel

Example	If A ^(a)	Then	
		B ^(a)	C ^(a)
	860 mm	10 mm	45 mm
	910 mm	35 mm	20 mm

- (a) **A:** Ceiling opening
B: Distance between the unit and the ceiling opening
C: Overlap between the decoration panel and the suspended ceiling


- **Installation guide.** Use the installation guide to determine the correct vertical position.

4 Installation



- A In case of installation with standard decoration panel
- B In case of installation with fresh air intake kit
- C In case of installation with self-cleaning decoration panel
- D In case of installation with design decoration panel
- a Suspended ceiling
- b Installation guide (accessory)
- c Unit

- **Level.** Make sure the unit is level at all 4 corners using a level or a water-filled vinyl tube.



- a Level
- b Vinyl tube
- c Water level

NOTICE

Do NOT install the unit tilted. **Possible consequence:** If the unit is tilted against the direction of the condensate flow (the drain piping side is raised), the float switch might malfunction and cause water to drip.


4.1.2 Guidelines when installing the drain piping

Make sure condensation water can be evacuated properly. This involves:

- General guidelines
- Connecting the drain piping to the indoor unit
- Checking for water leaks

General guidelines

- **Pipe length.** Keep drain piping as short as possible.
- **Pipe size.** Keep the pipe size equal to or greater than that of the connecting pipe (vinyl pipe of 25 mm nominal diameter and 32 mm outer diameter).
- **Slope.** Make sure the drain piping slopes down (at least 1/100) to prevent air from being trapped in the piping. Use hanging bars as shown.




- a Hanging bar
- O Allowed
- X Not allowed

- **Rising piping.** If necessary to make the slope possible, you can install rising piping.

- Drain hose inclination: 0~75 mm to avoid stress on the piping and to avoid air bubbles.


- Rising piping: ≤300 mm from the unit, ≤675 mm perpendicular to the unit.



- a Metal clamp (accessory)
- b Drain hose (accessory)
- c Rising drain piping (vinyl pipe of 25 mm nominal diameter and 32 mm outer diameter) (field supply)
- d Hanging bars (field supply)

- **Condensation.** Take measures against condensation. Insulate the complete drain piping in the building.

- **Combining drain pipes.** You can combine drain pipes. Make sure to use drain pipes and T-joints with a correct gauge for the operating capacity of the units.




a T-joint

To connect the drain piping to the indoor unit

NOTICE

Incorrect connection of the drain hose might cause leaks, and damage the installation space and surroundings.

- 1 Push the drain hose as far as possible over the drain pipe connection.
- 2 Tighten the metal clamp until the screw head is less than 4 mm from the metal clamp part.
- 3 Check for water leaks (see "To check for water leaks" [p 7]).
- 4 Install the insulation piece (drain pipe).
- 5 Wind the large sealing pad (= insulation) around the metal clamp and drain hose, and fix it with tie wraps.
- 6 Connect the drain piping to the drain hose.




- a Drain pipe connection (attached to the unit)
- b Drain hose (accessory)
- c Metal clamp (accessory)
- d Large sealing pad (accessory)
- e Insulation piece (drain pipe) (accessory)
- f Drain piping (field supply)

To check for water leaks


The procedure differs depending on whether electrical wiring is already finished. When electrical wiring is not finished yet, you need to temporarily connect the user interface and power supply to the unit.

When electrical wiring is not finished yet

- 1 Temporarily connect electrical wiring.
 - Remove the switch box cover (a).
 - Connect the user interface (b).
 - Connect the power supply (1~ 220-240 V 50/60 Hz) and earth (c).
 - Reattach the switch box cover (a).



- 2 Turn ON the power.
- 3 Start cooling operation (see "6.2 To perform a test run" [p 10]).
- 4 Gradually pour approximately 1 l of water through the air discharge outlet, and check for leaks.



- a Plastic watering can
- b Service drain outlet (with rubber plug). Use this outlet to drain water from the drain pan.
- c Drain pump location
- d Drain pipe connection
- e Drain pipe

- 5 Turn OFF the power.
- 6 Disconnect the electrical wiring.
 - Remove the switch box cover.
 - Disconnect the power supply and earth.
 - Disconnect the user interface.
 - Reattach the switch box cover.

When electrical wiring is finished already

- 1 Start cooling operation (see "6.2 To perform a test run" [p 10]).
- 2 Gradually pour approximately 1 l of water through the air discharge outlet, and check for leaks (see "When electrical wiring is not finished yet" [p 7]).

4.2 Connecting the refrigerant piping



DANGER: RISK OF BURNING/SCALDING

4.2.1 To connect the refrigerant piping to the indoor unit



CAUTION

Install the refrigerant piping or components in a position where they are unlikely to be exposed to any substance which may corrode components containing refrigerant, unless the components are constructed of materials that are inherently resistant to corrosion or are suitably protected against corrosion.




WARNING: MILDLY FLAMMABLE MATERIAL

The R32 refrigerant (if applicable) in this unit is mildly flammable. Refer to the outdoor unit specifications for the type of refrigerant to be used.

- **Pipe length.** Keep refrigerant piping as short as possible.
- **Flare connections.** Connect refrigerant piping to the unit using flare connections.
- **Insulation.** Insulate the refrigerant piping on the indoor unit as follows:

4 Installation



- A** Gas piping
B Liquid piping

- a** Insulation material (field supply)
b Tie wrap (accessory)
c Insulation pieces: Large (gas pipe), small (liquid pipe) (accessories)
d Flare nut (attached to the unit)
e Refrigerant pipe connection (attached to the unit)
f Unit
g Sealing pads: Medium 1 (gas pipe), medium 2 (liquid pipe) (accessories)

- 1 Turn up the seams of the insulation pieces.
- 2 Attach to the base of the unit.
- 3 Tighten the tie wraps on the insulation pieces.
- 4 Wrap the sealing pad from the base of the unit to the top of the flare nut.



NOTICE

Make sure to insulate all refrigerant piping. Any exposed piping might cause condensation.

4.3 Connecting the electrical wiring



DANGER: RISK OF ELECTROCUTION



WARNING

ALWAYS use multicore cable for power supply cables.



WARNING

Use an all-pole disconnection type breaker with at least 3 mm between the contact point gaps that provide full disconnection under overvoltage category III.



WARNING

If the supply cord is damaged, it MUST be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

4.3.1 Specifications of standard wiring components

Component	Specification
Interconnection cable (indoor↔outdoor)	4-core cable 1.5 mm ² ~2.5 mm ² and applicable for 220~240 V H05RN-F (60245 IEC 57)
User interface cable	Vinyl cords with 0.75 to 1.25 mm ² sheath or cables (2-core wires) Maximum 500 m H03VV-F (60227 IEC 52)

4.3.2 To connect the electrical wiring to the indoor unit



NOTICE

- Follow the wiring diagram (delivered with the unit, located at the inside of the service cover).
- For instructions on how to connect the decoration panel and the sensor kit, see the installation manual delivered with the panel or the kit.
- Make sure the electrical wiring does NOT obstruct proper reattachment of the service cover.

It is important to keep the power supply and the transmission wiring separated from each other. In order to avoid any electrical interference the distance between both wirings should ALWAYS be at least 50 mm.



NOTICE

Be sure to keep the power line and transmission line apart from each other. Transmission wiring and power supply wiring may cross, but may NOT run parallel.


- 1 Remove the service cover.
- 2 **User interface cable:** Route the cable through the frame, connect the cable to the terminal block, and fix the cable with a cable tie.
- 3 **Interconnection cable (indoor↔outdoor):** Route the cable through the frame, connect the cable to the terminal block (make sure the numbers match with the numbers on the outdoor unit, and connect the earth wire), and fix the cable with a cable tie.
- 4 Divide the small sealing (accessory) and wrap it around the cables to prevent water from entering the unit. Seal all gaps to prevent small animals from entering the system.




WARNING

Provide adequate measures to prevent that the unit can be used as a shelter by small animals. Small animals that make contact with electrical parts can cause malfunctions, smoke or fire.

- 5 Reattach the service cover.
- Following installation is for pair type or multi-system. For more installation options, see the Installer reference guide of the indoor unit.



- a** Interconnection cable
b Power supply cable
c Earth leakage circuit breaker
d Fuse
e1 Main user interface



- a Service cover (with wiring diagram on the back)
b Opening for cables
c Connection of interconnection cable (including earth)
d Cable tie
e Connection of user interface cable

5 Configuration

5.1 Field setting

Make the following field settings so that they correspond with the actual installation setup and with the needs of the user:

- Ceiling height
- Design decoration panel (if applicable)
- Air flow direction
- Air volume when thermostat control is OFF
- Time to clean air filter

Setting: Ceiling height

This setting must correspond with the actual distance to the floor, capacity class and airflow directions.

- For 3-way and 4-way airflow (which require an optional blocking pad kit), see the installation manual of the optional blocking pad kit.
- For all-round air flow, use the table below.

If the distance to the floor is (m)	Then ⁽¹⁾		
FCAHG71~140	M	C1	C2
≤3.2	13 (23)	0	01
3.2<x≤3.6			02
3.6<x≤4.2			03

Setting: Decoration panel type

When installing or changing the decoration panel type, ALWAYS check if the correct values are set.


If the ... decoration panel is used	Then ⁽¹⁾		
	M	C1	C2
Standard or self-cleaning	13	15	01
Design	(23)		02

Setting: Air flow direction

This setting must correspond with the actual used air flow directions. See the installation manual of the optional blocking pad kit and the manual of the user interface.

Default: 01 (= all-round air flow)

Example:



- a All-round air flow
b 4-way air flow (all air outlets open, 2 corners closed)
(optional blocking pad kit required)
c 3-way air flow (1 air outlet closed, all corners open)
(optional blocking pad kit required)

Setting: Air volume when thermostat control is OFF

This setting must correspond with the needs of the user. It determines the fan speed of the indoor unit during thermostat OFF condition.

- If you have set the fan to operate, set the air volume speed:

If you want...		Then ⁽¹⁾		
		M	C1	C2
During thermostat OFF at cooling operation	LL ⁽²⁾	12	6	01
	Setup volume ⁽²⁾	(22)		02
	OFF			03
	Monitoring 1 ⁽²⁾			04
	Monitoring 2 ⁽²⁾			05
During thermostat OFF at heating operation	LL ⁽²⁾	12	3	01
	Setup volume ⁽²⁾	(22)		02
	OFF			03
	Monitoring 1 ⁽²⁾			04
	Monitoring 3 ⁽²⁾			05

Setting: Time to clean air filter

This setting must correspond with the air contamination in the room. It determines the interval at which the **TIME TO CLEAN AIR FILTER** notification is displayed on the user interface. When using a wireless user interface, you must also set the address (see the installation manual of the user interface).

If you want an interval of... (air contamination)	Then ⁽¹⁾		
	M	C1	C2
±2500 h (light)	10 (20)	0	01
±1250 h (heavy)			02
No notification		3	02

⁽¹⁾ Field settings are defined as follows:

- M**: Mode number – **First number**: for group of units – **Number between brackets**: for individual unit
- C1**: First code number
- C2**: Second code number
- : Default

⁽²⁾ Fan speed:

- LL**: Low fan speed (set during thermostat OFF)
- L**: Low fan speed (set by the user interface)
- Setup volume**: The fan speed corresponds to the speed the user has set using the fan speed button on the user interface.
- Monitoring 1, 2, 3**: The fan is OFF, but runs for a short time every 6 minutes to detect the room temperature by **LL** (Monitoring 1), **Setup volume** (Monitoring 2) or **L** (Monitoring 3).

6 Commissioning

Individual setting in a simultaneous operation system

We recommend using the optional user interface to set the slave unit.


Perform the following steps:

- 2 Change the second code number to 02 to perform individual setting on the slave unit.

If you want to set the slave unit as...	Then ⁽¹⁾		
	M	C1	C2
Unified setting	21(11)	01	01
Individual setting			02

- 3 Perform field setting for the master unit.
- 4 Turn off the main power supply switch.
- 5 Disconnect the remote controller from the master unit and connect it to the slave unit.
- 6 Change to individual setting.
- 7 Perform field setting for the slave unit.
- 8 Turn off the main power supply or, in case of more slave units, repeat the previous steps for all slave units.
- 9 Disconnect the user interface from the slave unit and reconnect it to the master unit.

It is not necessary to rewire the remote controller from the master unit if the optional user interface is used. (However, remove the wires attached to the user interface terminal board of the master unit)



- A Master unit
- B Slave unit
- a Interconnection cable
- b Power supply cable
- c Earth leakage circuit breaker
- d Fuse
- e1 Main user interface
- e2 Optional user interface

6 Commissioning



NOTICE

ALWAYS operate the unit with thermistors and/or pressure sensors/switches. If NOT, burning of the compressor might be the result.

6.1 Checklist before commissioning

After the installation of the unit, first check the items listed below. Once all checks are fulfilled, the unit must be closed. Power-up the unit after it is closed.

<input type="checkbox"/>	You read the complete installation instructions, as described in the installer reference guide .
<input type="checkbox"/>	The indoor units are properly mounted.
<input type="checkbox"/>	In case a wireless user interface is used: The indoor unit decoration panel with infrared receiver is installed.
<input type="checkbox"/>	The outdoor unit is properly mounted.
<input type="checkbox"/>	There are NO missing phases or reversed phases .
<input type="checkbox"/>	The system is properly earthed and the earth terminals are tightened.
<input type="checkbox"/>	The fuses or locally installed protection devices are installed according to this document, and have NOT been bypassed.
<input type="checkbox"/>	The power supply voltage matches the voltage on the identification label of the unit.
<input type="checkbox"/>	There are NO loose connections or damaged electrical components in the switch box.
<input type="checkbox"/>	The insulation resistance of the compressor is OK.
<input type="checkbox"/>	There are NO damaged components or squeezed pipes on the inside of the indoor and outdoor units.
<input type="checkbox"/>	There are NO refrigerant leaks .
<input type="checkbox"/>	The correct pipe size is installed and the pipes are properly insulated.
<input type="checkbox"/>	The stop valves (gas and liquid) on the outdoor unit are fully open.

6.2 To perform a test run

This task is only applicable when using the BRC1E52 or BRC1E53 user interface. When using any other user interface, see the installation manual or service manual of the user interface.



NOTICE

Do NOT interrupt the test run.



INFORMATION

Backlight. To perform an ON/OFF action on the user interface, the backlight does not need to be lit. For any other action, it needs to be lit first. The backlight is lit for ±30 seconds when you press a button.








- 1 Perform introductory steps.

#	Action
1	Open the liquid stop valve and gas stop valve by removing the cap and turning counterclockwise with a hex wrench until it stops.
2	Close the service cover to prevent electric shocks.
3	Turn ON power for at least 6 hours before starting operation to protect the compressor.
4	On the user interface, set the unit to cooling operation mode.

⁽¹⁾ Field settings are defined as follows:







- **M:** Mode number – **First number:** for group of units – **Number between brackets:** for individual unit
- **C1:** First code number
- **C2:** Second code number
- **■:** Default

2 Start the test run


#	Action	Result
1	Go to the home menu.	
2	Press at least 4 seconds. 	The Service Settings menu is displayed.
3	Select Test Operation. 	
4	Press. 	Test Operation is displayed on the home menu. 
5	Press within 10 seconds. 	Test run starts.




3 Check operation for 3 minutes.

4 Check operation of the airflow direction (only applicable for indoor units with swing flaps).

#	Action	Result
1	Press. 	
2	Select Position 0. 	
3	Change the position. 	If the airflow flap of the indoor unit moves, operation is OK. If not, operation is not OK.
4	Press. 	The home menu is displayed.

5 Stop the test run.

#	Action	Result
1	Press at least 4 seconds. 	The Service Settings menu is displayed.

#	Action	Result
2	Select Test Operation. 	
3	Press. 	The unit returns to normal operation, and the home menu is displayed.

6.3 Error codes when performing a test run

If the installation of the outdoor unit has NOT been done correctly, the following error codes may be displayed on the user interface:

Error code	Possible cause
Nothing displayed (the currently set temperature is not displayed)	<ul style="list-style-type: none"> The wiring is disconnected or there is a wiring error (between power supply and outdoor unit, between outdoor unit and indoor units, between indoor unit and user interface). The fuse on the outdoor or indoor unit PCB has blown.
E3, E4 or L8	<ul style="list-style-type: none"> The stop valves are closed. The air inlet or air outlet is blocked.
E7	<p>There is a missing phase in case of three-phase power supply units.</p> <p>Note: Operation will be impossible. Turn OFF the power, recheck the wiring, and switch two of the three electrical wires.</p>
L4	The air inlet or air outlet is blocked.
U0	The stop valves are closed.
U2	<ul style="list-style-type: none"> There is a voltage imbalance. There is a missing phase in case of three-phase power supply units. Note: Operation will be impossible. Turn OFF the power, recheck the wiring, and switch two of the three electrical wires.
U4 or UF	The inter-unit branch wiring is not correct.
UA	The outdoor and indoor unit are incompatible.

7 Disposal



NOTICE


Do NOT try to dismantle the system yourself: dismantling of the system, treatment of the refrigerant, oil and other parts MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.

8 Technical data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin Business Portal (authentication required).

8 Technical data

8.1 Piping diagram: Indoor unit



8.2 Wiring diagram

8.2.1 Unified wiring diagram legend

For applied parts and numbering, refer to the wiring diagram on the unit. Part numbering is by Arabic numbers in ascending order for each part and is represented in the overview below by "*" in the part code.

Symbol	Meaning	Symbol	Meaning
	Circuit breaker		Protective earth
	Connection		Protective earth (screw)
	Connector		Rectifier
	Earth		Relay connector
	Field wiring		Short-circuit connector
	Fuse		Terminal
	Indoor unit		Terminal strip
	Outdoor unit		Wire clamp
	Residual current device		

Symbol	Colour	Symbol	Colour
BLK	Black	ORG	Orange
BLU	Blue	PNK	Pink
BRN	Brown	PRP, PPL	Purple
GRN	Green	RED	Red
GRY	Grey	WHT	White
		YLW	Yellow

Symbol	Meaning
A*P	Printed circuit board
BS*	Pushbutton ON/OFF, operation switch
BZ, H*O	Buzzer
C*	Capacitor
AC*, CN*, E*, HA*, HE*, HL*, HN*, HR*, MR*_A, MR*_B, S*, U, V, W, X*A, K*R*_*, NE	Connection, connector
D*, V*D	Diode
DB*	Diode bridge
DS*	DIP switch
E*H	Heater

Symbol	Meaning
FU*, F*U, (for characteristics, refer to PCB inside your unit)	Fuse
FG*	Connector (frame ground)
H*	Harness
H*P, LED*, V*L	Pilot lamp, light emitting diode
HAP	Light emitting diode (service monitor green)
HIGH VOLTAGE	High voltage
IES	Intelligent eye sensor
IPM*	Intelligent power module
K*R, KCR, KFR, KHuR, K*M	Magnetic relay
L	Live
L*	Coil
L*R	Reactor
M*	Stepper motor
M*C	Compressor motor
M*F	Fan motor
M*P	Drain pump motor
M*S	Swing motor
MR*, MRCW*, MRM*, MRN*	Magnetic relay
N	Neutral
n=*, N=*	Number of passes through ferrite core
PAM	Pulse-amplitude modulation
PCB*	Printed circuit board
PM*	Power module
PS	Switching power supply
PTC*	PTC thermistor
Q*	Insulated gate bipolar transistor (IGBT)
Q*C	Circuit breaker
Q*DI, KLM	Earth leak circuit breaker
Q*L	Overload protector
Q*M	Thermo switch
Q*R	Residual current device
R*	Resistor
R*T	Thermistor
RC	Receiver
S*C	Limit switch
S*L	Float switch
S*NG	Refrigerant leak detector
S*NPH	Pressure sensor (high)
S*NPL	Pressure sensor (low)
S*PH, HPS*	Pressure switch (high)
S*PL	Pressure switch (low)
S*T	Thermostat
S*RH	Humidity sensor
S*W, SW*	Operation switch
SA*, F1S	Surge arrester
SR*, WLU	Signal receiver
SS*	Selector switch
SHEET METAL	Terminal strip fixed plate
T*R	Transformer
TC, TRC	Transmitter
V*, R*V	Varistor

Symbol	Meaning
V*R	Diode bridge, Insulated-gate bipolar transistor (IGBT) power module
WRC	Wireless remote controller
X*	Terminal

Symbol	Meaning
X*M	Terminal strip (block)
Y*E	Electronic expansion valve coil
Y*R, Y*S	Reversing solenoid valve coil
Z*C	Ferrite core
ZF, Z*F	Noise filter

For the user

9 About the system

The indoor unit of this split system air conditioner can be used for heating/cooling applications.



NOTICE

Do NOT use the system for other purposes. In order to avoid any quality deterioration, do NOT use the unit for cooling precision instruments, food, plants, animals, or works of art.



NOTICE

For future modifications or expansions of your system:

A full overview of allowable combinations (for future system extensions) is available in technical engineering data and should be consulted. Contact your installer to receive more information and professional advice.

10 User interface



CAUTION

- NEVER touch the internal parts of the controller.
- Do NOT remove the front panel. Some parts inside are dangerous to touch and appliance problems may happen. For checking and adjusting the internal parts, contact your dealer.

This operation manual offers a non-exhaustive overview of the main functions of the system.

For more information about the user interface, see the operation manual of the installed user interface.

11 Before operation



WARNING

This unit contains electrical and hot parts.



WARNING

Before operating the unit, be sure the installation has been carried out correctly by an installer.



CAUTION

It is unhealthy to expose your body to the air flow for a long time.



CAUTION

To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the system.



CAUTION

Do NOT operate the system when using a room fumigation-type insecticide. Chemicals could collect in the unit, and endanger the health of people who are hypersensitive to chemicals.



NOTICE

Be sure to turn ON the power 6 hours before operation in order to have power running to the crankcase heater and to protect the compressor.

This operation manual is for the following systems with standard control. Before initiating operation, contact your dealer for the operation that corresponds to your system type and mark. If your installation has a customised control system, ask your dealer for the operation that corresponds to your system.

Operation modes:

- Heating and cooling (air to air).
- Fan only operation (air to air).

12 Operation

12.1 Operation range

Use the system in the following temperature and humidity ranges for safe and effective operation.

In combination with R410A outdoor units			
Outdoor units		Cooling	Heating
RZQG71~140	Outdoor temperature	–15~50°C DB	–20~15.5°C WB
	Indoor temperature	12~28°C WB	10~27°C DB
RZQSG71~140	Outdoor temperature	–15~46°C DB	–15~15.5°C WB
	Indoor temperature	14~28°C WB	10~27°C DB
Indoor humidity		≤80% ^(a)	

^(a) To avoid condensation and water dripping out of the unit. If the temperature or the humidity is beyond these conditions, safety devices may be put in action and the air conditioner may not operate.

In combination with R32 outdoor units		
	Cooling	Heating
Outdoor temperature	–20~52°C DB	–20~24°C DB –20~18°C WB
Indoor temperature	17~38°C DB 12~28°C WB	10~27°C DB
Indoor humidity	≤80% ^(a)	

12 Operation

^(a) To avoid condensation and water dripping out of the unit. If the temperature or the humidity is beyond these conditions, safety devices may be put in action and the air conditioner may not operate.

12.2 Operating the system

12.2.1 About operating the system

- To protect the unit, turn on the main power switch 6 hours before operation.
- If the main power supply is turned off during operation, operation will restart automatically after the power turns back on again.

12.2.2 About cooling, heating, fan only, and automatic operation

- The air flow rate may adjust itself depending on the room temperature or the fan may stop immediately. This is not a malfunction.

12.2.3 About the heating operation

It may take longer to reach the set temperature for general heating operation than for cooling operation.

The following operation is performed in order to prevent the heating capacity from dropping or cold air from blowing.


Defrost operation

In heating operation, freezing of the outdoor unit's air cooled coil increases over time, restricting the energy transfer to the outdoor unit's coil. Heating capability decreases and the system needs to go into defrost operation to be able to remove frost from the outdoor unit's coil. During defrost operation the heating capacity on the indoor unit side will temporarily drop until defrosting is completed. After defrosting, the unit will regain its full heating capacity.

The indoor unit will stop fan operation, the refrigerant cycle will reverse and energy from inside the building will be used to defrost the outdoor unit coil.

The indoor unit will indicate defrost operation on the display .


Hot start

In order to prevent cold air from blowing out of an indoor unit at the start of heating operation, the indoor fan is automatically stopped. The display of the user interface shows . It may take some time before the fan starts. This is not a malfunction.

12.2.4 To operate the system

- 1 Press the operation mode selector button on the user interface several times and select the operation mode of your choice.

 Cooling operation

 Heating operation

 Fan only operation

- 2 Press the ON/OFF button on the user interface.

Result: The operation lamp lights up and the system starts operating.

12.3 Using the dry program

12.3.1 About the dry program

- The function of this program is to decrease the humidity in your room with minimal temperature decrease (minimal room cooling).
- The micro computer automatically determines temperature and fan speed (cannot be set by the user interface).

- The system does not go into operation if the room temperature is low ($<20^{\circ}\text{C}$).

12.3.2 To use the dry program

To start

- 1 Press the ON/OFF button of the user interface.

Result: The operation lamp lights up and the system starts operating.

To stop

- 2 Press the ON/OFF button on the user interface once again.

Result: The operation lamp goes out and the system stops operating.



NOTICE

Do not turn off power immediately after the unit stops, but wait for at least 5 minutes.

12.4 Adjusting the air flow direction

Refer to the operation manual of the user interface.

12.4.1 About the air flow flap





Double flow+multi-flow units

For the following conditions, a micro computer controls the air flow direction which may be different from the display.

Cooling	Heating
<ul style="list-style-type: none">▪ When the room temperature is lower than the set temperature.	<ul style="list-style-type: none">▪ When starting operation.▪ When the room temperature is higher than the set temperature.▪ At defrost operation.
<ul style="list-style-type: none">▪ When operating continuously at horizontal air flow direction.▪ When continuous operation with downward air flow is performed at the time of cooling with a ceiling-suspended or a wall-mounted unit, the micro computer may control the flow direction, and then the user interface indication will also change.	

The air flow direction can be adjusted in one of the following ways:

- The air flow flap itself adjusts its position.
- The air flow direction can be fixed by the user.
- Automatic  and desired position .




WARNING

Never touch the air outlet or the horizontal blades while the swing flap is in operation. Fingers may become caught or the unit may break down.



NOTICE

- The movable limit of the flap is changeable. Contact your dealer for details. (only for double-flow, multi-flow, corner, ceiling-suspended and wall-mounted).
- Avoid operating in the horizontal direction . It may cause dew or dust to settle on the ceiling or flap.

12.5 Active circulation airflow

Use active circulation airflow to heat or cool the room more quickly.

12.5.1 To start the active circulation airflow

- 1 Set the active circulation airflow

1	Go to the home screen.	
2	Press.	
3	Select Circulation airflow	
4	Choose enable and confirm.	
5	Confirm setting.	
6	Go to the home screen.	
7	Check if Air Volume/direction is set to automatic. If not set to automatic.	

2 Turn on the unit by the user interface.

13 Maintenance and service

13.1 Precautions for maintenance and service



CAUTION

Do NOT insert fingers, rods or other objects into the air inlet or outlet. When the fan is rotating at high speed, it will cause injury.



NOTICE

NEVER inspect or service the unit by yourself. Ask a qualified service person to perform this work. However, as end user, you may clean the air filter, suction grille, air outlet and outside panels.



WARNING

NEVER replace a fuse with a fuse of a wrong ampere ratings or other wires when a fuse blows out. Use of wire or copper wire may cause the unit to break down or cause a fire.



CAUTION

After a long use, check the unit stand and fitting for damage. If damaged, the unit may fall and result in injury.



NOTICE

Do NOT wipe the controller operation panel with benzine, thinner, chemical dust cloth, etc. The panel may get discoloured or the coating peeled off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the panel clean. Wipe it with another dry cloth.



CAUTION

Before accessing terminal devices, make sure to interrupt all power supply.



NOTICE

When cleaning the heat exchanger, make sure to remove the switch box, fan motor, drain pump and float switch. Water or detergent might deteriorate the insulation of electronic components and result in burnout of these components.

13.2 Cleaning the air filter, suction grille, air outlet and outside panels



CAUTION

Turn off the unit before cleaning the air filter, suction grille, air outlet and outside panels.

13.2.1 To clean the air filter

When to clean the air filter:

- Rule of thumb: Clean every 6 months. If the air in the room is extremely contaminated, increase the cleaning frequency.
- Depending on the settings, the user interface can display the **TIME TO CLEAN AIR FILTER** notification. Clean the air filter when the notification is displayed.
- If the dirt becomes impossible to clean, change the air filter (= optional equipment).

How to clean the air filter:




NOTICE

Do NOT use water of 50°C or higher. **Possible consequence:** Discoloration and deformation.


- Open the suction grille.

Standard panel:




13 Maintenance and service

Design panel:




2 Remove the air filter.


Standard panel:



Design panel:



3 Clean the air filter. Use a vacuum cleaner or wash with water. If the air filter is very dirty, use a soft brush and neutral detergent.



4 Dry the air filter in the shadow.

5 Reattach the air filter and close the suction grille.

6 Turn ON the power.

7 Press the **FILTER SIGN RESET** button.

Result: The **TIME TO CLEAN AIR FILTER** notification disappears from the user interface.


13.2.2 To clean the suction grille

! NOTICE


Do NOT use water of 50°C or higher. **Possible consequence:** Discoloration and deformation.

1 Open the suction grille.

Standard panel:




Design panel:




2 Remove the suction grille.


Standard panel:



Design panel:



3 Remove the air filter.



4 Clean the suction grille. Wash with a soft bristle brush, and water or neutral detergent. If the suction grille is very dirty, use a typical kitchen cleaner, leave it on for 10 min, then wash it with water.

5 Reattach the air filter (step 3 in reverse order).

6 Reattach the suction grille and close it (step 2 and 1 in reverse order).

13.2.3 To clean the air outlet and outside panels



WARNING

Do NOT let the indoor unit get wet. **Possible consequence:** Electric shock or fire.



NOTICE

- Do NOT use gasoline, benzene, thinner polishing powder or liquid insecticide. **Possible consequence:** Discoloration and deformation.
- Do NOT use water or air of 50°C or higher. **Possible consequence:** Discoloration and deformation.
- Do NOT scrub firmly when washing the blade with water. **Possible consequence:** The surface sealing peels off.

Clean with a soft cloth. If it is difficult to remove stains, use water or neutral detergent.

13.3 Maintenance after a long stop period

E.g., at the beginning of the season.

- Check and remove everything that might be blocking inlet and outlet vents of indoor units and outdoor units.
- Clean air filters and casings of indoor units (see "[13.2.1 To clean the air filter](#)" [p 15] and "[13.2.3 To clean the air outlet and outside panels](#)" [p 16]).
- Turn on the power at least 6 hours before operating the unit in order to ensure smoother operation. As soon as the power is turned on, the user interface display appears.

13.4 Maintenance before a long stop period

E.g., at the end of the season.

- Let the indoor units run in fan only operation for about half a day in order to dry the interior of the units. Refer to "[12.2.2 About cooling, heating, fan only, and automatic operation](#)" [p 14] for details on fan only operation.
- Turn off the power. The user interface display disappears.
- Clean air filters and casings of indoor units (see "[13.2.1 To clean the air filter](#)" [p 15] and "[13.2.3 To clean the air outlet and outside panels](#)" [p 16]).

13.5 About the refrigerant

This product contains fluorinated greenhouse gases. Do NOT vent gases into the atmosphere.

Refrigerant type: R32

Global warming potential (GWP) value: 675

Refrigerant type: R410A

Global warming potential (GWP) value: 2087.5



NOTICE

Applicable legislation on **fluorinated greenhouse gases** requires that the refrigerant charge of the unit is indicated both in weight and CO₂ equivalent.

Formula to calculate the quantity in CO₂ equivalent tonnes: GWP value of the refrigerant × total refrigerant charge [in kg] / 1000

Please contact your installer for more information.



WARNING: MILDLY FLAMMABLE MATERIAL

The R32 refrigerant (if applicable) in this unit is mildly flammable. Refer to the outdoor unit specifications for the type of refrigerant to be used.



WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).



WARNING

- Do NOT pierce or burn refrigerant cycle parts.
- Do NOT use cleaning materials or means to accelerate the defrosting process other than those recommended by the manufacturer.
- Be aware that the refrigerant inside the system is odourless.



WARNING

R410A is a non-combustible refrigerant, and R32 is a mildly flammable refrigerant; they normally don't leak. If the refrigerant leaks in the room and comes into contact with fire from a burner, a heater, or a cooker, this may result in a fire (in case of R32), or the formation of a harmful gas.

Turn off any combustible heating devices, ventilate the room, and contact the dealer from where you purchased the unit.

Do not use the unit until a service person confirms that the part from which the refrigerant leaked has been repaired.

14 Troubleshooting

If one of the following malfunctions occur, take the measures shown below and contact your dealer.



WARNING

Stop operation and shut off the power if anything unusual occurs (burning smells etc.).

Leaving the unit running under such circumstances may cause breakage, electric shock or fire. Contact your dealer.

The system MUST be repaired by a qualified service person.

Malfunction	Measure
If a safety device such as a fuse, a breaker or an earth leakage breaker frequently actuates or the ON/OFF switch does NOT properly work.	Turn OFF the main power switch.
If water leaks from the unit.	Stop the operation.
The operation switch does NOT work well.	Turn OFF the power supply.
If the user interface display indicates the unit number, the operation lamp flashes and the malfunction code appears.	Notify your installer and report the malfunction code.

If the system does NOT operate properly except for the above mentioned cases and none of the above mentioned malfunctions is evident, investigate the system in accordance with the following procedures.



INFORMATION

Refer to the reference guide located on <http://www.daikineurope.com/support-and-manuals/product-information/> for more troubleshooting tips.



If after checking all above items, it is impossible to fix the problem yourself, contact your installer and state the symptoms, the complete model name of the unit (with manufacturing number if possible) and the installation date (possibly listed on the warranty card).



15 Disposal



NOTICE

Do NOT try to dismantle the system yourself: dismantling of the system, treatment of the refrigerant, oil and other parts MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.







DAIKIN INDUSTRIES CZECH REPUBLIC s.r.o.

U Nové Hospody 1/1155, 301 00 Plzeň Skvrňany, Czech Republic

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

Copyright 2018 Daikin

4P535639-1D 2021.07