

7

Piping diagramsPiping Diagrams

EBBH-D6V ① Space heating - water OUT ② Space heating - water IN | Pump
| Space heating water pressure sensor
| R1T - Outlet water heat exchanger thermistor
| R2T - Outlet water backup heater thermistor
| R3T - Thermistor (heat exchanger, liquid pipe)
| R4T - Inlet water thermistor EBBH-D9W) Shut-off valve) Magnetic filter / dirt separator) Safety valve EBBX-D6V EBBX-D9W Air purge Drain valve Flow sensor
 Plate heat exchanger 10 Expansion vessel 11 Backup heater Water side Refrigerant side Field installed ① ③]-JJ-]-(9) Condenser Field installed 1-3 Screw connection Brazed connection Quick coupling 3D133750