




A1P	Printed circuit board (main)
A2P	Printed circuit board (noise filter)
A4P	Printed circuit board (ACS)
BS1 ~ BS3 (A1P)	Push-button switch
C1 ~ C619 (A1P)	Capacitor
DS1 (A1P)	DIP switch
E1H	Drain tube heater (field supply)
E1HHEX	PHE heater
F1U	Field fuse (field supply)
F1U, F3U (A2P)	Fuse (T 6.3A / 250V)
F4U, F5U (A2P)	Fuse (T 30A / 500V)
F7U (A1P)	Fuse (T 5.0A / 250V)
HAP (A1P)	Light-emitting diode (service monitor is green)
K1R (A1P)	Magnetic relay (Y1S)
K1R (A4P)	Magnetic relay (E1HHEX)
K2R (A1P)	Magnetic relay (Y2S)
K2R (A4P)	Magnetic relay (E1H)
K3R (A1P)	Magnetic relay (Y3S)
K10R ~ K84R (A1P)	Magnetic relay
K1M ~ K2M (A1P)	Magnetic contactor
L2R ~ L9R (A1P)	Reactor
M1C	Motor (compressor)
M1F	Motor (fan)
PS (A1P)	Switching power supply
Q1DI	Earth leakage circuit breaker (30mA)(field supply)
Q1	Thermal overcurrent protector
R2 ~ R807 (A1P)	Resistor
R1T	Thermistor (ambient)
R2T	Thermistor (discharge)
R3T	Thermistor (suction)
R4T	Thermistor (heat exchanger liquid pipe)
R5T	Thermistor (heat exchanger middle)
R6T	Thermistor (refrigerant liquid)
R7T	Thermistor (injection)
R9T	Thermistor (inlet water)
R10T	Thermistor (outlet water)
R11T	Thermistor (fin)
RC (A1P)	Signal receiver circuit
S1NPH	High pressure sensor
S1PH~S2PH	High pressure switch
SEG* (A1P)	7-segment display
TC (A1P)	Signal transmission circuit
V1D ~ V3D (A1P)	Diode

V1R ~ V2R (A1P)	Diode module
V3R ~ V5R (A1P)	IGBT power module
X1M ~ X2M	Terminal strip
Y1E	Electronic expansion valve (main - black)
Y3E	Electronic expansion valve (injection - blue)
Y1S	Solenoid valve (4-way valve)
Y2S	Solenoid valve (low pressure bypass)
Y3S	Solenoid valve (hot gas bypass)
Y4S	Solenoid valve (liquid injection)
Z1C ~ Z10C	Noise filter (ferrite core)
Z1F ~ Z5F (A1P,A2P)	Noise filter

NOTES

- L : Live

⊕ : Protective earth

□□ : Terminal strip

□□ : Connector

|||| : Field wiring

----- : Wiring depending on model
- N : Neutral

⚡ : Noiseless earth

○- : Terminal

● : Connection

① : Several wiring possibilities

== : Option
- Colours: blk:black; red:red; blu:blue; wht:white; grn:green; ylw:yellow; pnk:pink; org:orange; gry:grey; brn:brown
- This wiring diagram applies only to the outdoor unit.
- When operating, do not short-circuit protection device Q1, S1PH and S2PH.
- Terminal strip
- Refer to the combination table and the option manual for how to connect the wiring to X5A, X77A, X41A and X2M.
- The factory setting of all switches is OFF, do not change the setting of the selector switch (DS1).