


7 Dimensional drawings

7 - 1 Dimensional Drawings

FXFA-A

Notes

- Location of nameplate
The unit nameplate is located on the control box cover.
The decoration panel nameplate is located on the piping-side panel frame, under the corner cover.
- When installing optional accessories, refer to their respective documentation.
- Make sure the distance between the ceiling and the cassette does not exceed -35-mm.
- The maximum ceiling opening is -910-mm.
When the conditions in the ceiling exceed 30°C ambient temperature and 80% relative humidity, or when fresh air is inducted into the ceiling, additional insulation is required (polyethylene foam, thickness ≥ 10-mm).
- When installing a sensor kit, there will be a sensor on this location. For details, see the drawing of the sensor kit.
- When installing a wireless controller, there will be a receiver on this location. For details, see the drawing of the wireless controller.




2D121703D

FXFA-A

Notes

- Location of nameplate
The unit nameplate is located on the control box cover.
The decoration panel nameplate is located on the piping-side panel frame, under the corner cover.
- When installing optional accessories, refer to their respective documentation.
- Make sure the distance between the ceiling and the cassette does not exceed -35-mm.
- The maximum ceiling opening is -910-mm.
When the conditions in the ceiling exceed 30°C ambient temperature and 80% relative humidity, or when fresh air is inducted into the ceiling, additional insulation is required (polyethylene foam, thickness ≥ 10-mm).
- When installing a sensor kit, there will be a sensor on this location. For details, see the drawing of the sensor kit.




2D121658D

7 Dimensional drawings

7 - 2 Dimensional Drawings with Accessories


FXFA-A

Remote control dimensions




Remote control holder

Installation methods
Installation to wall surface



Installation methods




Front panel	Model name	Option
Decoration panel	BYCQ140E2W1(W)	BRC7FA532F
	BYCQ140E2W1B	BRC7FA532FB
Self-cleaning decoration panel	BYCQ140E2GFW1	BRC7FA532F
	BYCQ140E2GFW1B	BRC7FA532FB
Designer decoration panel	BYCQ140E2P	BRC7FB532F
	BYCQ140E2PB	BRC7FB532FB

3D121750

FXFA-A

Installation methods



Front panel	Model name	Option
Decoration panel	BYCQ140E2W1(W)	BRYQ140B8
	BYCQ140E2W1B	BRYQ140B8B
Self-cleaning decoration panel	BYCQ140E2GFW1	BRYQ140B8
	BYCQ140E2GFW1B	BRYQ140B8B
Designer decoration panel	BYCQ140E2P	BRYQ140C8
	BYCQ140E2PB	BRYQ140C8B

3D121755